



TOSTADOR PLANO

TH-TP102

Por favor, lea cuidadosamente este manual antes de usar el tostador por primera vez.

Guarde el manual para futuras consultas.

Estimado cliente:

Agradecemos la confianza depositada en nosotros al adquirir este producto THULOS®. Nuestro principal empeño es ofrecer artículos excelentes, manteniendo los más estrictos controles de calidad y cumpliendo todas las normativas vigentes de seguridad, con el objetivo de presentar un producto perfecto y seguro para el uso doméstico.

Lea detenidamente el presente manual de instrucciones y guárdelo para posterior consulta. En caso de entregar el aparato a terceros, entregue también el presente manual de instrucciones.

PRECAUCIÓN

MANTENGA TODO EL EMBALAJE, CAJA, PLÁSTICOS, ETC. HASTA QUE COMPRUEBE EL BUEN FUNCIONAMIENTO DE SU TOSTADOR.

Asegúrese de que su tostador no esté dañado. En caso de duda, NO LO USE y póngase en contacto con nuestro servicio postventa o el establecimiento donde lo compró. Por seguridad, mantenga todos los envases (bolsas de plástico, cajas, polietileno, etc.) fuera del alcance de niños o animales.

Antes de enchufar el aparato a la red eléctrica, verifique que la tensión se corresponda con la indicada en la placa de características. Se recomienda el uso de una toma de tierra.

INSTRUCCIONES GENERALES DE SEGURIDAD

- Antes de utilizar el aparato, compruebe que la tensión de la red es la misma que la de las características o que se indica en los Datos técnicos al final de este manual.
- Este aparato ha sido diseñado solo para uso doméstico y en interiores. No lo utilice para fines profesionales o externos.
- Este dispositivo puede ser utilizado por niños de 8 años de edad o mayores y personas con capacidades físicas, sensoriales o mentales reducidas o falta de experiencia y conocimiento, si se les ha dado la supervisión o la instrucción adecuadas con respecto al uso del dispositivo en un lugar seguro, manera y entender los peligros involucrados. Los niños no deben jugar con el aparato. La limpieza y el mantenimiento que debe realizar el usuario no deben ser realizados por niños a menos que tengan más de 8 años y estén bajo supervisión. Mantenga el aparato y su cable fuera del alcance de los niños.
- El aparato no está diseñado para ser operado por medio de un temporizador externo o un sistema de control remoto separado.
- Nunca deje su aparato desatendido cuando esté en uso.
- Compruebe regularmente que el cable no esté dañado. No use su aparato si el cable o el aparato están dañados y llévelo a un técnico de servicio calificado.
- Nunca sumerja el aparato en agua o cualquier otro líquido, para limpiarlo o por cualquier otro motivo. Nunca lo limpie en el lavavajillas.
- No lo use cerca de fuentes de calor.
- El enchufe de alimentación debe desenchufarse antes de limpiar el aparato.
- Cualquier reparación debe ser realizada por un técnico de servicio calificado.
- No utilice el aparato al aire libre y colóquelo en un lugar seco.
- No lo deje al aire libre.
- No utilice accesorios no recomendados por el fabricante, esto puede presentar un riesgo para el usuario y dañar el dispositivo. Utilice únicamente accesorios y repuestos originales.

- Nunca mueva el aparato tirando del cable. Asegúrese de que el cable no quede enganchado en un saliente para evitar posibles caídas. Evite girar el cable alrededor del aparato o girarlo.
- Coloque el aparato sobre una superficie suficientemente plana y estable para evitar que se caiga.
- Deje que el aparato se enfríe antes de limpiarlo y guardarlo.
- Asegúrese de que el aparato no entre en contacto con materiales fácilmente inflamables, como cortinas, telas, etc. Cuando esté en funcionamiento, ya que podría provocar un incendio. Deje una distancia mínima de un metro entre el aparato y los materiales inflamables.
- No limpie el aparato con utensilios metálicos o abrasivos para evitar el riesgo de cortocircuitos y dañar las superficies del acabado.
- No cubra el aparato ni sus orificios de ventilación, ya que podría provocar un incendio.

INSTRUCCIONES ESPECIALES DE SEGURIDAD

- Este dispositivo solo debe ser tocado por las asas laterales.
- No mueva su tostadora mientras está funcionando.
- La rejilla superior puede permanecer caliente unos minutos después del último uso.
- La superficie exterior se calienta durante el funcionamiento, tenga cuidado de no tocarla.
- Retire la bandeja después de cada uso.
- No use su tostadora para descongelar alimentos.

USO

- Inserte el enchufe en un enchufe con conexión a tierra.
- Durante el primer uso, gire la mando del temporizador al máximo sin pan en la parrilla. Su tostadora emitirá olor y humo, esto es normal y desaparecerá después de este primer uso.
- Poner el pan en la rejilla. Siempre deje un espacio de 1 cm entre cada rebanada, para evitar el sobrecalentamiento de su tostadora.
- Gire la mando del temporizador a la posición deseada. Las resistencias se encenderán lentamente.
- Después del tiempo establecido, sonará una campana y la tostadora se apagará automáticamente.
- Puede interrumpir el tostado en cualquier momento girando la perilla del temporizador a 0.

LIMPIEZA Y MANTENIMIENTO

- Desconecte y deje que se enfríe el tostador antes de limpiarlo.
- No sumerja su tostador en agua o cualquier líquido. La superficie exterior se puede limpiar con un paño limpio y húmedo.
- Si continúan las manchas, se puede usar agua jabonosa, evitando que entren a través de las ranuras de ventilación.
- No use limpiadores abrasivos ni utensilios afilados para limpiar la superficie exterior.
- La bandeja de recogida puede retirarse para su limpieza. Para hacer esto, tire de la ranura inferior hacia afuera. Una vez limpio y seco, insértelo con cuidado en su ranura.

Atención

El incumplimiento de las recomendaciones de uso y limpieza de este manual puede resultar en la pérdida parcial o total de la garantía.

La manipulación por parte del personal que no sea el fabricante puede causar la pérdida parcial o total de la garantía.

Datos técnicos:

Modelo: TH-TP102

Voltaje: 220-240V, 50/60Hz

Potencia: 600W

Este dispositivo ha sido aprobado de acuerdo con todas las directivas de la UE (CE, RoHS), así como las directrices de compatibilidad electromagnética y de baja tensión, y se ha construido de acuerdo con las normas de seguridad.

CONDICIONES DE GARANTÍA

- Por la presente se garantiza la calidad de este producto según plazos y condiciones de la legislación vigente.
- Quedan excluidos de esta garantía todos aquellos aparatos que presenten golpes o manipulaciones incorrectas, así como las deficiencias ocasionadas por un uso anormal o abusivo.
- La empresa, se reserva el derecho a elegir entre reparar, sustituir o canjear por otro de características similares, en función del tipo de avería o de las existencias de nuestros almacenes.
- El producto está garantizado contra todo defecto de fabricación.

NORMAS DE PROTECCIÓN DEL MEDIOAMBIENTE



Este aparato no se debe desechar con los residuos domésticos cuando finalice su durabilidad, sino que se debe ofrecer a un centro de reciclaje de aparatos eléctricos y electrónicos domésticos. Este símbolo en el aparato, manual de instrucciones y embalaje le avisa de este aspecto importante. Los materiales utilizados en este aparato se pueden reciclar. Mediante el reciclaje de electrodomésticos, usted contribuye a fomentar la protección del medioambiente. Consulte a sus autoridades locales para obtener información acerca del punto de recogida



FLAT TOASTER

TH-TP102

For you safety and continued enjoyment of this product.
Always read the instruction book carefully before using.

Dear Customer:

We thank you very much for having purchased this THULOS® product. We kindly ask you to read and save this instruction manual.

Please read these operating instructions carefully and keep them in a safe place. If you pass the unit on to someone else, please give them these operating instructions as well.

CAUTION

KEEP ALL PACKAGING, BOX, PLASTICS, ETC. UNTIL YOU CHECK THE GOOD OPERATION OF YOUR TOASTER.

Make sure your toaster is not damaged. In case of doubt, DO NOT USE IT and contact our after-sales service or the establishment where you purchased it.

For safety, please keep all packaging (plastic bags, boxes, polystyrene, etc.) out of the reach of children or animals.

Before plugging the appliance into the mains supply, check that the voltage corresponds with that stated on the characteristics plate. The use of an earthed socket is recommended.

GENERAL SECURITY INDICATION

- Before using the appliance, check that the mains voltage is same as the one on the characteristics or with the one indicated in the Technical Data at end of this manual.
- This appliance has been designed for domestic use only and indoors. Do not use it for professional or external purposes.
- This appliance may be used by children 8 years of age or older and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge, if they have been given appropriate supervision or instruction regarding to the use of the appliance in a safe manner and understand the hazards involved. Children should not play with the appliance. The cleaning and maintenance to be performed by the user should not be performed by children unless they are over 8 years old and under supervision. Keep the appliance and its cord out of reach of children.
- The appliance is not intended to be operated by means of an external timer or a separate remote control system.
- Never leave your appliance unattended when it is in use.
- Check regularly that the cable is not damaged. Do not use your appliance if the cord or appliance is damaged and take it to a qualified service technician.
- Never immerse the appliance in water or any other liquid, for cleaning or for any other reason. Never insert it in the dishwasher, except for the parts indicated in the Cleaning section.
- Do not use near heat sources.
- The power plug must be unplugged before cleaning the appliance.
- Any repairs should be performed by a qualified service technician.
- Do not use the appliance outdoors and place it in a dry place.
- Do not leave it out in the open.
- Do not use attachments not recommended by the manufacturer, this may present a risk to the user and may damage the device. Use only original accessories and spare parts.
- Never move the appliance by pulling on the cord. Make sure that the cable does not get caught in any protrusions in order to avoid possible falls. Avoid twisting the cord around the appliance or

twisting it around.

- Place the appliance on a sufficiently flat and stable surface to prevent it from falling.
- Let the appliance cool down before cleaning and storing.
- Ensure that the appliance does not come into contact with easily flammable materials such as curtains, fabrics, etc. When it is in operation, as it could cause a fire. Leave a minimum distance of one meter between the apparatus and flammable materials.
- Do not clean the appliance with metal or abrasive utensils to avoid the risk of short circuits and damage the surfaces of the finish.
- Do not cover the appliance or its ventilation holes as this could result in a fire.

SPECIAL SAFETY INSTRUCTIONS

- This device should only be touched by the side handles.
- Do not move your toaster while it is running.
- The top rack may remain hot minutes after last use.
- The exterior surface heats up during operation, be careful not to touch it.
- Remove the tray after each use.
- Do not use your toaster to defrost food.

USE

- Insert the plug into a grounded plug.
- During the first use, turn the timer knob to maximum without bread on the grill. Your toaster will emit smell and smoke, this is normal and will disappear after this first use.
- Put the bread on the rack. Always leave a 1cm gap between each slice, to avoid overheating your toaster.
- Turn the timer knob to the desired position. The resistors will light up slowly.
- After the set time, a bell will sound and your toaster will turn off automatically.
- You can interrupt toasting at any time by turning the timer knob to 0.

CLEANING AND MAINTENANCE

- Unplug and allow to cool before cleaning your toaster.
- Do not immerse your toaster in water or any liquid. The exterior surface can be cleaned with a clean, damp cloth.
- If stains continue to occur, soapy water can be used, preventing them from entering through the ventilation slots.
- Do not use abrasive cleaners or sharp utensils to clean the exterior surface.
- The pickup tray can be removed for cleaning. To do this pull the lower groove out. Once clean and dry, carefully insert it into its slot.

Attention

Failure to follow the recommendations for use and cleaning of this manual may result in partial or total loss of warranty.

Handling by personnel other than the manufacturer may cause partial or total loss of the warranty.

Technical data:

Model: TH-TP102

Power supply: 220-240V, 50/60Hz

Power: 600W.

This device has been approved in accordance with all EU directives (CE, RoHS) as well as electromagnetic compatibility and low voltage guidelines, and has been built in accordance with safety regulations.

WARRANTY CONDITIONS

- The quality of this product according to terms and conditions of the current legislation is guaranteed.
- Excluded from this guarantee all those devices which have bumps or improper handling and defects caused by abnormal or abusive use.
- The company reserves the right to choose between repair, replace or exchanged for another with similar characteristics, depending on the type of damage or stocks from our warehouses.
- The product is guaranteed against all manufacturing defects.

GUIDELINES FOR PROTECTION OF THE ENVIRONMENT

Do not dispose of this product in the usual household garbage at the end of its life cycle; hand it over at a collection point for the recycling of electrical and electronic appliances. The symbol on the product, the instructions for use or the packing will inform about the methods for disposal.

 The materials are recyclable as mentioned in its marking. By recycling, material recycling or other forms of re-utilization of old appliances, you are making an important contribution to protect our environment. Please inquire at the community administration for the authorized disposal location.



TOSTADOR PLANO / FLAT TOASTER

TH-TP102



EAN: 8436572765405

www.thulos.com

thulos@thulos.com

Servicio Técnico / Technical Service: sat@grupothulos.com

