



POWER BANK 5000mAh



TH-PB104



ESPECIFICACIONES.

- Pantalla digital LCD
- Tipo de batería: batería de iones de litio
- Capacidad: 5000 mAh
- Entrada MicroUSB: DC5V/2.1A
- Entrada Tipo-C: DC5V/2.1A
- Salida Tipo-C: DC5V/2.1A
- Salida USB: DC5V/2.1A
- Incluye solamente un cable tipo MicroUSB.
- Peso: 95,6 g
- Dimensión: 38*24,8*79mm

ADVERTENCIAS POR Y PARA SU SEGURIDAD

- Mantener seco el aparato en todo momento.
- No usar en zonas con ambiente húmedo.
- El aparato pueden usarlo niños a partir de 8 años y por personas con capacidades físicas, sensoriales o mentales reducidas, o que no tengan experiencia ni conocimientos, si son supervisados o instruidos en el uso del aparato de forma segura y entienden los riesgos implicados.
- Este aparato no es un juego para niños.
- Solamente puede ser reparado por un servicio técnico autorizado.
- Nunca usar cerca de donde pueda haber agua u otro líquido.
- No usar cerca de aerosoles, sprays o productos con gas comprimido.
- No usar en bañeras, duchas ni cerca de depósitos llenos de agua.
- Este aparato solo es para uso doméstico y ocasional.
- Desenchufar de la corriente inmediatamente después de su carga.

CARGAR EL POWER BANK.

- Cargar el power bank al 100% antes del primer uso.
- Conectar un cable adecuado al puerto de entrada MicroUSB o Tipo-C.
- Conectar a un adaptador 5V/2A o al PC.
- No interrumpir la carga hasta que el display llega al 100%.

CARGAR DISPOSITIVO MEDIANTE EL POWER BANK.

- Este power bank puede cargar a su dispositivo mediante conector tipo USB o también mediante conector Tipo-C.
- Conectar el dispositivo a la salida Tipo-USB o Tipo-C del power bank, utilizando un cable adecuado.
- Esperar a que el dispositivo cargue la batería completa al 100%.



POWER BANK 5000mAh



TH-PB104



SPECIFICATIONS.

- LCD digital display
- Battery type: lithium-ion battery
- Capacity: 5000mAh
- Micro input: DC5V/2.1A
- Type-c input: DC5V/2.1A
- Type C output: DC5V/2.1A
- USB output: DC5V/2.1A
- Includes only a MicroUsb type cable.
- Weight: 95.6g
- Dimension: 38*24.8*79mm

WARNINGS BY AND FOR YOUR SAFETY

- Keep the appliance dry at all times.
- Do not use in areas with humid environment.
- The appliance can be used by children from 8 years old and by people with reduced physical, sensory or mental abilities, or who have no experience or knowledge, if they are supervised or instructed in the use of the device in a safe and understand the risks involved.
- This appliance is not a game for children.
- It can only be repaired by an authorized technical service.
- Never use near where there may be water or other liquid.
- Do not use near aerosols, sprays or products with compressed gas.
- Do not use in bathtubs, showers or near tanks full of water.
- This appliance is for domestic and occasional use only.
- Unplug from power immediately after charge.

CHARGE THE POWER BANK.

- Charge the power bank to 100% before first use.
- Connect a appropriate cable to the MicroUsb or Type-C input port.
- Connect to a 5V/2A adapter or to the PC.
- Do not interrupt charging until the display reaches 100%.

CHARGE DEVICE THROUGH THE POWER BANK.

- This power bank can charge your device through a connector Usb type or also through Type-C connector.
- Connect the device to the Type-Usb or Type-C output of the power bank, using a suitable cable.
- Wait for the device to charge the full battery to 100%.