THULOS®
WE MAKE THINGS BIG

LAMPARA PARA CAMPING CON BATERIA

TH-OA4001

8 436588 777904

ESPECIFICACIONES.

- 2 Fuentes de luz: filamento led (central) y Led superior.
- Brillo: 230 lúmenes.
- Capacidad de la batería: 1200 mAh.
- Entrada de carga para Adaptador 5V 1.0A. (No incluido).
- Incluye cable de carga Usb a Tipo-C.
- Potencia máxima: 4W
- Tiempo de carga: 6 horas.
- Indicador de batería llena.
- Duración： 4.5h (referencia aproximada según su uso).
- Intensidad de luz ajustable en 2 modos.

ADVERTENCIAS POR Y PARA SU SEGURIDAD

- Mantener seco el aparato en todo momento.
- No usar en zonas con ambiente húmedo.
- El aparato pueden usarlo niños a partir de 8 años y por personas con capacidades físicas, sensoriales o mentales reducidas, o que no tengan experiencia ni conocimientos, si son supervisados o instruidos en el uso del aparato de forma segura y entienden los riesgos implicados.
- La limpieza del aparato no puede hacerla los niños.
- Este aparato no es un juego para niños.
- Solamente puede ser reparado por un servicio técnico autorizado.
- Nunca usar cerca de donde pueda haber agua u otro líquido.
- No usar cerca de aerosoles, sprays o productos con gas comprimido.
- No usar en bañeras, duchas ni cerca de depósitos llenos de agua.
- Este aparato solo es para uso doméstico y ocasional.
- Nunca deje desatendido el aparato mientras esté en uso.

BATERÍA.

- Antes de usar por primera vez, debe cargar la batería al 100%.
- Si la batería se gasta, debe cargarla de inmediato.
- Mantener la batería siempre con carga aunque no lo use.
- Nunca cargar la batería con la lámpara encendida.
- Una vez cargando, nunca interrumpa la carga hasta el 100%.

FUNCIONAMIENTO.

- Para encender el filamento, girar el botón en sentido horario hasta escuchar un “click”.
- Si gira el botón hasta la mitad, se apaga el filamento y se encienden las luces led superiores. Si sigue girando en sentido horario puede ajustar hasta 2 niveles de intensidad de luz.
- Para apagar, girar el botón en sentido antihorario hasta escuchar un “click” y todas las luces queden apagadas.

LIMPIEZA Y CONSERVACIÓN.

- Limpiar con frecuencia con paño suave y seco para quitar el polvo.
- Limpiar siempre después de su uso y antes de guardar.
- Almacenar en zonas secas, libres de polvo y en su caja original.

THULOS®
WE MAKE THINGS BIG

CAMPING LAMP WITH BATTERY

TH-OA4001

8 436588 777904

SPECIFICATIONS.

- 2 light sources: led filament (central) and upper led.
- Brightness: 230 lumens.
- Battery capacity: 1200 mAh.
- Charging input for 5V 1.0A Adapter. (Not included).
- Includes Usb to Type-C charging cable.
- Maximum power: 4W
- Charging time: 6 hours.
- Full battery indicator.
- Duration： 4.5h (approximate reference according to its use).
- Light intensity adjustable in 2 modes.

WARNINGS BY AND FOR YOUR SAFETY

- Keep the appliance dry at all times.
- Do not use in areas with humid environment.
- The appliance can be used by children from 8 years of age and by people with reduced or no physical, sensory or mental capabilities have no experience or knowledge, if they are supervised or instructed in using the appliance safely and understand the risks involved.
- The appliance cannot be cleaned by children.
- This appliance is not a game for children.
- It can only be repaired by an authorized technical service.
- Never use near where there may be water or other liquid.
- Do not use near aerosols, sprays or products with compressed gas.
- Do not use in bathtubs, showers or near tanks full of water.
- This appliance is for domestic and occasional use only.
- Never leave the appliance unattended while it is in use.

BATTERY.

- Before using for the first time, you must charge the battery to 100%.
- If the battery runs out, you should charge it immediately.
- Always keep the battery charged.
- Never charge the battery with the lamp on.
- Once charging, never interrupt charging up to 100%.

OPERATION.

- To turn on the filament, turn the button clockwise until you hear a “click".
- If you turn the button halfway, the filament is turned off and the upper led lights. If you keep turning clockwise you can adjust up to 2 levels of light intensity.
- To turn off, turn the knob counterclockwise until you hear a click. “click” and all the lights are off.

CLEANING AND PRESERVATION.

- Clean frequently with a soft, dry cloth to remove dust.
- Always clean after use and before storing.
- Store in dry, dust-free areas and in its original box.