LAMPARA DE CAMPING CON LINTERNA

TH-OA4002

8 436588 777928

ESPECIFICACIONES.

- Linterna con opción ráfagas y luz inferior con 2 tonos de luz.
- Ajuste de intensidad de luz.
- Capacidad de la batería: 2x 1200 mAh.
- Entrada de carga Tipo-C para Adaptador 5V 1.0A. (No incluido).
- El tiempo de carga depende del tipo de adaptador.
- Indicador de nivel de carga.
- Función Power Bank para cargar su teléfono o dispositivo externo.
- Panel solar: 5V – 0.3W.
- Duración de carga de la batería: de 3 a 12 horas, según su uso.

ADVERTENCIAS POR Y PARA SU SEGURIDAD

- Mantener seco el aparato en todo momento.
- No usar en zonas con ambiente húmedo.
- El aparato pueden usarlo niños a partir de 8 años y por personas con capacidades físicas, sensoriales o mentales reducidas, o que no tengan experiencia ni conocimientos, si son supervisados o instruidos en el uso del aparato de forma segura y entienden los riesgos implicados.
- La limpieza del aparato no puede hacerla los niños.
- Este aparato no es un juego para niños.
- Solamente puede ser reparado por un servicio técnico autorizado.
- Nunca usar cerca de donde pueda haber agua u otro líquido.
- No usar cerca de aerosoles, sprays o productos con gas comprimido.
- No usar en bañeras, duchas ni cerca de depósitos llenos de agua.
- Nunca deje desatendido el aparato mientras esté en uso.

BATERÍA.

- Antes de usar por primera vez, debe cargar la batería al 100%.
- Si la batería se gasta, debe cargarla de inmediato.
- Mantener la batería siempre con carga aunque no lo use.
- Nunca cargar la batería con la lámpara encendida.
- Una vez cargando, nunca interrumpa la carga hasta el 100%.

FUNCIONAMIENTO.

- Pulsación corta: Enciende, cambia de tono de luz y apaga.
- Manteniendo pulsado: ajusta la intensidad de luz.

- Conector USB: para conectar y cargar un dispositivo externo.
- Conector Tipo-C: para cargar la batería de la lámpara.

- Para encender la linterna delantera pulse el botón ⏻ delantero.
- Pulse para encender, hacer ráfagas y apagar.

LIMPIEZA Y CONSERVACIÓN.

- Limpiar con frecuencia con paño suave y seco para quitar el polvo.
- Limpiar siempre después de su uso y antes de guardar.
- Almacenar en zonas secas, libres de polvo y en su caja original.

THULOS®
WE MAKE THINGS BIG

CAMPING LAMP WITH LANTERN

TH-OA4002

8 436588 777928

SPECIFICATIONS.

- Flashlight with burst option and lower light with 2 light tones.
- Light intensity adjustment.
- Battery capacity: 2x 1200 mAh.
- Type-C charging input for 5V 1.0A Adapter. (Not included).
- The charging time depends on the type of adapter.
- Charge level indicator.
- Power Bank function to charge your mobile phone or external device.
- Solar panel: 5V – 0.3W.
- Battery charge duration: from 3 to 12 hours, depending on its use.

WARNINGS BY AND FOR YOUR SAFETY

- Keep the appliance dry at all times.
- Do not use in areas with humid environment.
- The appliance can be used by children from 8 years of age and by people with reduced or no physical, sensory or mental capabilities have no experience or knowledge, if they are supervised or instructed in using the appliance safely and understand the risks involved.
- The appliance cannot be cleaned by children.
- This appliance is not a game for children.
- It can only be repaired by an authorized technical service.
- Never use near where there may be water or other liquid.
- Do not use near aerosols, sprays or products with compressed gas.
- Do not use in bathtubs, showers or near tanks full of water.
- Never leave the appliance unattended while it is in use.

BATTERY.

- Before using for the first time, you must charge the battery to 100%.
- If the battery runs out, you should charge it immediately.
- Always keep the battery charged.
- Never charge the battery with the lamp on.
- Once charging, never interrupt charging up to 100%.

OPERATION.

- Short press: Turn on, change light tone and turn off.
- Holding press: adjusts the light intensity.

- USB connector: to connect and charge an external device.
- Type-C connector: to charge the lamp battery.

- To turn on the front lantern, press the front button ⏻.
- Press to turn on, burst and turn off.

CLEANING AND PRESERVATION.

- Clean frequently with a soft, dry cloth to remove dust.
- Always clean after use and before storing.
- Store in dry, dust-free areas and in its original box.