

CAFETERA ELÉCTRICA GOTEO



MANUAL DE INSTRUCCIONES

ET-CM61



Estimado Cliente:

Agradecemos la confianza depositada en nosotros al adquirir este producto ELECTROTEK.

Nuestro principal empeño es ofrecer artículos excelentes, manteniendo los más estrictos controles de calidad y cumpliendo todas las normativas vigentes de seguridad, con el objetivo de presentar un producto perfecto y seguro para el uso doméstico.

Lea detenidamente el presente manual de instrucciones y guárdelo para posterior consulta.

En caso de entregar el aparato a terceros, entregue también el presente manual de instrucciones.

INSTRUCCIONES PARA SU SEGURIDAD.

- Aparato diseñado solamente para uso doméstico.
- Limpie bien el aparato antes de utilizarlo por primera vez.
- Antes de enchufarlo verifique que la corriente y potencia coincidan con la de la etiqueta del aparato.
- No use el aparato mojado, mesa mojada ó con las manos mojadas.
- Nunca intente reparar el aparato por usted mismo.
- No deje el cable colgando, sobresaliendo de la mesa donde tenga el aparato.
- Si usa una extensión de cable, debe ser el adecuado para el consumo del aparato, de lo contrario podría sobrecalentarse y quemarse.
- Coloque el aparato en una mesa firme, nivelada y resistente al calor.
- Este aparato no es un juego para niños.
- No es apto para que lo usen los niños.
- No deje el aparato desatendido mientras esté en uso y enchufado.
- Si un niño usa este aparato, lo hará bajo la entera responsabilidad de los padres.
- Desenchufar el aparato inmediatamente después de su uso.
- Si desea agregar café ó agua durante su funcionamiento, apáguela primero, añada el café o el agua y luego vuélvala a encender.
- Si no hay agua en el tanque, apáguela.
- Use solamente agua limpia.
- No toque la placa con el dispositivo encendido ó recién apagado, podría quemar.
- Después de varios usos, debe limpiarse completamente con agua tibia y detergente neutro.
- No encienda la cafetera con el tanque vacío.
- Este electrodoméstico no está destinado a ser utilizado por personas (incluidos niños) con capacidades físicas, sensoriales o mentales reducidas, por falta de experiencia y conocimiento, a menos que se les haya supervisado ó instruido sobre el uso del aparato por la persona responsable de su seguridad.

FUNCIONAMIENTO.

- Limpie completamente el aparato antes de usarlo por primera vez.
- Desmonte y limpie todos sus accesorios por separado.
- Abra la tapa del tanque y vierta agua limpia al nivel deseado.
- Ponga el café molido deseado en el filtro permanente.
- Coloque el filtro con el café en la cesta del filtro.
- Coloque la jarra de vidrio sobre la placa.
- Enchufe la cafetera.
- Pulse el interruptor y se iluminará.
- Al cabo de unos segundos la cafetera empezará a funcionar.
- Cuando esté listo el café, apague la cafetera y luego retire la jarra.
- Desenchufe de la corriente eléctrica.
- Si mantiene la jarra sobre la placa caliente, su café se mantendrá caliente mientras dure el calor de la placa.

LIMPIEZA Y MANTENIMIENTO.

- Antes de limpiar el aparato desenchufe siempre de la corriente eléctrica.
- Nunca sumergir el aparato en agua. Limpiar con un paño húmedo y secar.
- Los elementos extraíbles como el filtro, porta-filtro ó bandeja de goteo, se pueden lavar con agua caliente o en el lavavajillas.
- Descalcifique regularmente la cafetera con un descalcificador para cafeteras siguiendo sus instrucciones de dosificación por cantidad de agua.
- Descalcifique la cafetera una vez cada trimestre.
- Después de descalcificar, póngala 2 veces solo con agua y tanque lleno para eliminar posibles restos de detergente.
- Limpie la parte exterior con paños húmedos suaves y detergentes neutros.
- Nunca utilice estropajos ni productos abrasivos ó corrosivos.
- Mantenga el aparato alejado de zonas calientes.
- Si el aparato no funciona correctamente o está dañado, llévelo al servicio especializado para que lo reparen.
- Si el cable o enchufe están dañados, no utilice el aparato.
- En cualquier caso, nunca intente reparar usted mismo el aparato.
- Debe ser reparado en un servicio técnico especializado.

ESPECIFICACIONES TÉCNICAS.

- Voltaje: 220-240V~50/60Hz.
- Potencia: 550 W.
- Capacidad: 5-6 Tazas.

CONDICIONES DE GARANTÍA.

1. ESTE APARATO ESTA CUBIERTO CONTRA CUALQUIER DEFECTO DE FÁBRICA.
2. EL APARATO SE CAMBIARÁ SIEMPRE Y CUANDO ESTÉ DENTRO DEL PLAZO DE CAMBIO Y SE DEVUELVA CON TODOS SUS ACCESORIOS Y EMBALAJE.
3. LA GARANTÍA SERÁ VÁLIDA SIEMPRE Y CUANDO EL APARATO VAYA ACOMPAÑADO DE SU FACTURA Ó TICKET DE COMPRA DONDE SALGA REFLEJADO EL APARATO,

Ó TAMBIÉN SU TARJETA DE GARANTÍA DEBIDAMENTE CUMPLIMENTADA Y SELLADA.

4. EL APARATO ESTARÁ EXENTO DE GARANTÍA (NO CUBIERTO) CUANDO:

- 4.1. EL APARATO TENGA SEÑALES DE GOLPES Y/O CAÍDAS.
- 4.2. EL APARATO PRESENTE SIGNOS DE MAL USO.
- 4.3. EL APARATO PRESENTE SIGNOS DE USO EXCESIVO.
- 4.4. EL APARATO ESTÉ MANIPULADO INADECUADAMENTE.
- 4.5. NO TENGA DOCUMENTO ACREDITATIVO (TARJETA, TICKET Ó FACTURA COMPRA).
- 4.6. EL APARATO NO SE HA USADO SEGÚN LAS INSTRUCCIONES DE USO.

NOTAS:

- **BAJO NINGÚN CONCEPTO SE HARÁ CAMBIO DIRECTO Ó ABONO DIRECTO**
SIN ANTES REVISAR EL APARATO Y LAS CAUSAS POR LAS QUE SE HA AVERIADO.

NORMAS DE PROTECCIÓN DEL MEDIO AMBIENTE



Este aparato no se debe desechar con los residuos domésticos cuando finalice su durabilidad, sino que se debe ofrecer a un centro de reciclaje de aparatos eléctricos y electrónicos domésticos. Este símbolo en el aparato, manual de instrucciones y embalaje le avisa de este aspecto importante. El/los materiales utilizados en este aparato se pueden reciclar. Mediante el reciclaje de electrodomésticos, usted contribuye a fomentar la protección del medioambiente. Consulte a sus autoridades locales para obtener información acerca del punto de recogida.

ELECTRIC COFFEE MAKER OF DRIP



INSTRUCTIONS MANUAL

ET-CM61



Dear Customer:

We appreciate the confidence placed in us when purchasing this ELECTROTEK product.

Our main commitment is to offer excellent items, maintaining the strictest quality controls and complying with all current safety regulations, in order to present a perfect and safe product for domestic use.

Read this instruction manual carefully and save it for later reference.

If you deliver the device to third parties, also deliver this instruction manual.

INSTRUCTIONS FOR YOUR SAFETY.

- Apparatus designed only for domestic use.
- Clean the device thoroughly before using it for the first time.
- Before plugging in, check that the current and power match that of the appliance label.
- Do not use wet equipment, wet table or wet hands.
- Never try to repair the appliance yourself.
- Do not leave the cable hanging protruding from the table where you have the device.
- If you use a cable extension, it must be suitable for the consumption of the device, otherwise it could overheat and burn.
- Place the appliance on a firm, level and heat resistant table.
- This device is not a game for children.
- It is not suitable for children to use.
- Do not leave the appliance unattended while it is in use and plugged in.
- If a child uses this device, it will be done under the full responsibility of the parents.
- Unplug the appliance immediately after use.
- If you want to add coffee or water during operation, turn it off first, add the coffee or water and then turn it on again.
- If there is no water in the tank, turn it off.
- Use only clean water.
- Do not touch the board with the device on or just turned off, it could burn.
- After several uses, it should be thoroughly cleaned with warm water and neutral detergent.
- Do not turn on the coffee maker with the tank empty.
- This appliance is not intended to be used by people (including children) with reduced physical, sensory or mental abilities, or lack of experience and knowledge, unless they have been supervised or instructed on the use of the device by the person responsible for your safety.

OPERATION.

- Clean the appliance completely before using it for the first time.
- Disassemble and clean all accessories separately.
- Open the tank lid and pour clean water to the desired level.
- Put the desired ground coffee in the permanent filter.

- Place the filter with the coffee in the filter basket.
- Place the glass jar on the plate.
- Plug in the coffee maker.
- Press the switch and it will light up.
- After a few seconds the coffeemaker will start working.
- When the coffee is ready, turn off the coffee maker and then remove the carafe.
- Unplug the electric current.
- If you keep the jug on the hot plate, your coffee will stay warm while the heat of the plate lasts.

CLEANING AND MAINTENANCE.

- Always unplug the power supply before cleaning the appliance.
- Never immerse the appliance in water. Wipe clean with a damp cloth and dry.
- Removable elements such as filter, filter holder or drip tray, are they can be washed with hot water or in the dishwasher.
- Regularly decalcify the coffee machine with a coffeemaker decalcifier following your dosing instructions by quantity of water.
- Decalcify the coffee maker once every quarter.
- After decalcifying, put it 2 times only with water and full tank for remove possible detergent residues.
- Clean the outside with soft damp cloths and neutral detergents.
- Never use scourers or abrasive or corrosive products.
- Keep the appliance away from hot areas.
- If the appliance does not work properly or is damaged, take it to the service specialized to repair it.
- If the cable or plug is damaged, do not use the appliance.
- In any case, never try to repair the device yourself.
- It must be repaired in a specialized technical service.

SPECIFICATIONS.

- Voltage: 220-240V~50/60Hz.
- Power: 550W.
- Capacity: 5-6 Cups.

WARRANTY CONDITIONS.

1. This appliance is covered against any factory defects.
2. The device is changed for a new one as long as it is within the change period and is
returned with all accessories and packaging in good condition.
3. The guarantee will be valid as long as the appliance is accompanied by your invoice or
purchase ticket where the exact device and model, or your warranty card duly completed and sealed, is reflected.
4. THE APPLIANCE WILL BE EXEMPT FROM WARRANTY WHEN:

- 4.1. The appliance has signs of knocks and / or falls.
- 4.2. The appliance shows signs of misuse.
- 4.3. The appliance has signs of overuse.
- 4.4. The appliance is improperly handled.
- 4.5. No supporting document. (Card, ticket or invoice).
- 4.6. The appliance has not been used in accordance with the instructions for use.

NOTES.

- Under no circumstances will direct change or direct payment be made without first reviewing the device and the causes for which it has failed.

GUIDELINES FOR PROTECTION OF THE ENVIRONMENT



This appliance should not be put in to the domestic garbage at the end of its durability, but must be offered at a central point for there cycling of electric and electronic domestic appliances. This symbol on the appliance, instruction manual and pack again put your attention to this important issue.

The materials used in this appliance can be recycled. By recycling of used domestic appliances you contribute important push to the protection of our environment. Ask your local authorities for information regarding the point of recollection.



EAN: 8436568810737

www.thulos.com

Servicio Técnico:

sat@grupothulos.com

