



MANUAL DE INSTRUCCIONES
CAFETERA ELÉCTRICA
TH-CM750

Por favor, lea cuidadosamente este manual antes de usar la cafetera por primera vez.
Guarde el manual para futuras consultas.

ESPAÑOL

Agradecemos la confianza depositada en nosotros al adquirir este producto THULOS®. Nuestro principal empeño es ofrecer artículos excelentes, manteniendo los más estrictos controles de calidad y cumpliendo todas las normativas vigentes de seguridad, con el objetivo de presentar un producto perfecto y seguro para el uso doméstico.

SEGURIDAD

- Si ignora las instrucciones de seguridad, eximirá al fabricante de toda responsabilidad por posibles daños.
- Si el cable de alimentación está dañado contacte con el Servicio Técnico Oficial, no intente cambiarlo vd.
- Nunca mueva el aparato tirando del cable y asegúrese de que no se pueda enredar con el cable.
- El aparato debe colocarse sobre una superficie estable y nivelada.
- El usuario no debe dejar el dispositivo sin supervisión mientras esté conectado a la alimentación.
- Este aparato se debe utilizar únicamente para el uso doméstico y sólo para las funciones para las que se ha diseñado. Este aparato no debe ser utilizado por niños de 0 a 8 años. Este aparato puede ser utilizado por niños a partir de los 8 años si son supervisados de forma continua. Este aparato puede ser usado por personas con capacidades físicas, sensoriales o mentales reducidas, o falta de experiencia y conocimientos, si reciben supervisión o instrucciones sobre el uso del aparato de forma segura y comprenden los riesgos que implica. Los niños no pueden jugar con el aparato.
- Mantenga el aparato y el cable fuera del alcance de los

niños menores de 8 años. Los niños no podrán realizar la limpieza ni el mantenimiento reservado al usuario.

- Para protegerse contra una descarga eléctrica, no sumerja el cable, el enchufe ni el aparato en el agua o cualquier otro líquido.
- Este aparato se ha diseñado exclusivamente para uso doméstico.
- Los niños no pueden jugar con el aparato.
- Este aparato no debe ser utilizado por niños. Mantenga el aparato y el cable fuera del alcance de los niños.
- Para protegerse contra una descarga eléctrica, no sumerja el cable, el enchufe ni el aparato en el agua o cualquier otro líquido.

DESCRIPCIÓN DE LOS COMPONENTES



ANTES DEL PRIMER USO

- Saque el aparato y los accesorios de la caja. Retire la lámina protectora o el plástico del dispositivo.
- Coloque el dispositivo sobre una superficie plana estable y asegúrese de tener un mínimo de 10 cm de espacio libre alrededor del mismo. Este dispositivo no es apropiado para ser instalado en un armario o para el uso en exteriores.
- Conecte el cable de alimentación a la toma de corriente. (Nota: Asegúrese de que la tensión que se indica en el dispositivo coincida con la tensión local antes de conectarlo).
- Para obtener un sabor perfecto, realice 2 o 3 ciclos de ebullición con agua nueva cada vez (sin café). Cuando todo el agua haya pasado por el aparato, apáguelo y deje que se enfríe durante 5 minutos. A continuación repita el proceso con agua nueva.

USO

- Abra la tapa del depósito de agua y llénelo con la cantidad de agua deseada de acuerdo al número de tazas de café que desea.
- Abra el soporte del filtro. Añada la cantidad deseada de café molido en el filtro. Vuelva a poner el soporte del filtro.
- Asegúrese de que la jarra de cristal se sitúa correctamente sobre la placa de calor.
- Pulse el botón de encendido/apagado para encender la cafetera, un piloto rojo se encenderá.
- Una vez terminado el proceso, la cafetera mantendrá el café caliente y se apagará automáticamente durante 40

min. Si no necesita conservar el calor, por favor, pulse el interruptor y la cafetera dejará de funcionar.

LIMPIEZA Y MANTENIMIENTO

- Asegúrese de desenchufar la cafetera de la red eléctrica.
- Espere a que se enfríe completamente.
- Limpie el aparato con un paño húmedo. No utilice productos de limpieza abrasivos o fuertes, estropajos o lana metálica porque se podría dañar el aparato.
- No sumerja nunca el aparato en agua o cualquier otro líquido. El aparato no se puede lavar en el lavavajillas.

MEDIO AMBIENTE



Este aparato no debe desecharse con la basura doméstica al final de su vida útil, sino que se debe entregar en un punto de recogida para el reciclaje de aparatos eléctricos y electrónicos. Este símbolo en el aparato, manual de instrucciones y embalaje quiere atraer su atención sobre esta importante cuestión. Los materiales utilizados en este aparato se pueden reciclar. Mediante el reciclaje de electrodomésticos, usted contribuye a fomentar la protección del medioambiente. Solicite más información sobre los puntos de recogida a las autoridades locales.

CONDICIONES DE GARANTÍA

- Por la presente se garantiza la calidad de este producto según plazos y condiciones de la legislación vigente.
- Quedan excluidos de esta garantía todos aquellos aparatos que presenten golpes o manipulaciones incorrec-

tas, así como las deficiencias ocasionadas por un uso anormal o abusivo.

- La empresa, se reserva el derecho a elegir entre reparar, sustituir o canjear por otro de características similares, en función del tipo de avería o de las existencias de nuestros almacenes.
- El producto está garantizado contra todo defecto de fabricación.



**INSTRUCTION MANUAL
ELECTRIC COFFEE MAKER
TH-CM750**

For you safety and continued enjoyment of this product.
Always read the instruction book carefully before using.

ENGLISH

We thank you very much for having purchased this THULOS® product. We kindly ask you to read and save this instruction manual.

SAFETY

- By ignoring the safety instructions the manufacturer can not be hold responsible for the damage.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Never move the appliance by pulling the cord and make sure the cord can not become entangled.
- The appliance must be placed on a stable, level surface.
- The user must not leave the device unattended while it is connected to the supply.
- This appliance is only to be used for household purposes and only for the purpose it is made for.
- This appliance shall not be used by children from 0 year to 8 years. This appliance can be used by children aged from 8 years and above if they are continuously supervised. This appliance can be used by people with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Keep the appliance and its cord out of reach of children aged less than 8 years. Cleaning and user maintenance shall not be made by children.
- To protect yourself against an electric shock, do not im-

merse the cord, plug or appliance in the water or any other liquid.

- This appliance is intended to be used in household.
- Children shall not play with the appliance.
- This appliance shall not be used by children.
- Keep the appliance and its cord out of reach of children.
- To protect yourself against an electric shock, do not immerse the cord, plug or appliance in the water or any other liquid.

PARTS DESCRIPTION



BEFORE THE FIRST USE

- Take the appliance and accessories out the box. Remove the protective foil or plastic from the device.
- Place the device on a flat stable surface and ensure a minimum of 10 cm. free space around the device. This device is not suitable for installation in a cabinet or for outside use.
- Put the power cable into the socket. (Note: Make sure the voltage which is indicated on the device matches the local voltage before connecting the device.
- For a perfect taste, carry out 2 or 3 boil processes with fresh water (without coffee). Once all the water has passed through, switch the appliance off and let it cool down during 5 minutes. Then repeat the process with fresh water.

USE

- Pour the desired volume of water into the water reservoir. The number of cups can be read on the water level indicator.
- Add the desired quantity of ground coffee. Replace the filter holder.
- Make sure the glass can is placed correctly on the hot-plate.
- To switch on, press the on/off button, the coffee maker will start working and the red pilot light will light on.
- Wait until the brewing process is finished and the filter is empty. To switch off the coffee machine, press the on/off button. The red pilot light will go off to indicate that the coffee maker has been switched off.

- After finishing working, the unit will preserve coffee heat, and it will power off automatically in 40 minutes. If there is no need to preserve heat, please press switch and the unit will stop working.

CLEANING AND MAINTENANCE

- Be sure to unplug the power plug from electrical supply source before cleaning.
- Wait for the whole appliance cool down before cleaning
- Wipe the outside with only a slightly moistened cloth ensuring that no moisture, oil or grease enters the cooling slots.
- Clean the appliance with a damp cloth. Never use harsh and abrasive cleaners, scouring pad or steel wool, which damages the device.
- Never immerse the device in water or any other liquid. The device is not dishwasher proof.

ENVIRONMENT



Fixed width narrow. This appliance should not be put into the domestic garbage at the end of its durability, but must be offered at a central point for the recycling of electric and electronic domestic appliances. This symbol on the appliance, instruction manual and packaging puts your attention to this important issue. The materials used in this appliance can be recycled. By recycling of used domestic appliances you contribute an important push to the protection of our environment. Ask your local authorities for information regarding the point of recollection.

WARRANTY CONDITIONS

- The quality of this product according to terms and conditions of the current legislation is guaranteed.
- Excluded from this guarantee all those devices which have bumps or improper handling and defects caused by abnormal or abusive use.
- The company reserves the right to choose between repair, replace or exchanged for another with similar characteristics, depending on the type of damage or stocks from our warehouses.
- The product is guaranteed against all manufacturing defects.



CAFETERA ELÉCTRICA | ELECTRIC COFFEE MAKER

TH-CM750

EAN: 8436550626131

