

ES

Manual de instrucciones

Instrucciones de seguridad: Léalas cuidadosamente y guárdelas en un lugar seguro para futuras consultas.

Estimado cliente,

Gracias por comprar este producto. Le rogamos que lea el manual de instrucciones y lo guarde en un lugar seguro para futuras consultas.

EL KIT INCLUYE:

- Dispensador *1
- Cable USB *1
- Manguera *1
- Tubo Acero Inox. 304 *1
- Manual del Usuario *1

ADVERTENCIAS

- NO use este producto para bombear alcohol, otros líquidos corrosivos o aceite o agua caliente (+55°C)
- NO lo sumerja en Agua para su limpieza.

ESPECIFICACIONES

- Voltaje: 5.0V DC
- Potencia: 4W
- Batería: 1200 mAh. Li-Ion

INSTALACIÓN



FUNCIONAMIENTO

1. Cárguelo completamente antes de usarlo por primera vez.
2. Durante la carga se encenderá una luz indicadora en color rojo y cambiará a color verde o se apagará cuando la carga haya finalizado.

3. Presione el botón para bombear agua. Vuelva a pulsar el botón para parar su funcionamiento.

MANTENIMIENTO Y ALMACENAJE

1. La Manguera de Silicona y el Tubo de Acero Inox. pueden ser hervidos durante unos minutos antes de ser usado por primera vez y posteriormente cada 2 meses para una mejor higiene.
2. Se sugiere que la Manguera de Silicona sea reemplazada cada 6 meses para evitar cualquier posible problema de higiene.
3. Asegúrese de que NO haya residuos de agua en la unidad antes de almacenarla por un tiempo prolongado.

CONDICIONES DE GARANTÍA

1. Este aparato está cubierto contra cualquier defecto de fábrica.
2. El aparato se cambiará siempre y cuando esté dentro del plazo de cambio y se devuelva con todos sus accesorios y embalaje.
3. La garantía será válida siempre y cuando el aparato vaya acompañado de su factura o ticket de compra donde salga reflejado el aparato, o también su tarjeta de garantía debidamente cumplimentada y sellada.
4. El aparato estará exento de garantía (no cubierto) cuando:
 - 4.1. El aparato tenga señales de golpes y/o caídas.
 - 4.2. El aparato presente signos de mal uso.
 - 4.3. El aparato presente signos de uso excesivo.
 - 4.4. El aparato esté manipulado inadecuadamente.
 - 4.5. No tiene documento acreditativo (tarjeta, ticket o factura compra)
 - 4.6. El aparato no se ha usado según las instrucciones de uso.

MEDIO AMBIENTE



Significado del cubo de basura

No deseche los aparatos eléctricos como residuos municipales sin clasificar, use las instalaciones de recolección por separado. Póngase en contacto con el responsable local para obtener información sobre los sistemas de recolección disponibles.

Si los aparatos eléctricos se desechan en vertederos no controlados, las sustancias peligrosas pueden filtrarse en el agua subterránea y entrar en la cadena alimentaria, dañando su salud y bienestar.

EN

Instruction Manual

Safety instructions: Please read carefully and store in a safe place for future reference.

Dear Customer,

Thank you for purchasing this product. We kindly ask you to read the instruction manual and keep it in a safe place for future reference.

KIT INCLUDE:

Unit	*1
USB cable	*1
Inlet Hose	*1
Stainless Steel 304 Spout	*1
User Manual	*1

ATTENTION

- Please do NOT use this product to pump alcohol or other corrosive liquids such as oil, or water hot over 55°C.
- Please do NOT dip the product into water for cleaning.
- All product has been inspected pumping before delivery, please ignore it if there is any residue water in product.

SPECIFICATIONS

- Voltage: 5.0V DC
- Power: 4W
- Battery: 1200 mAh Li-Ion

INSTALLATION



OPERATION

1. Please CHARGE to full capacity before first use.
2. Indicator light turns red during charging, and turns green or off when charge is done.
3. Press the button to pump water. Press again to stop.

MAINTENANCE & STORAGE

- Silicone Hose & SS spout can be boiled for a few minutes before first use, and after every 2 months for better hygiene.
- It's suggested that Silicone Hose shall be replaced after 6 months use to avoid any potential hygiene issue.
- Make sure that there be NO water residue in the unit before any long time storage.

WARRANTY CONDITIONS

1. This appliance is covered against any factory defects.
2. The device is changed for a new one as long as it is within the change period and is returned with all accessories and packaging in good condition.
3. The guarantee will be valid as long as the appliance is accompanied by your invoice or purchase ticket where the exact device and model, or your warranty card duly completed and sealed, is reflected.
4. The appliance will be exempt from warranty when:
 - 4.1. The appliance has signs of knocks and / or falls.
 - 4.2. The appliance shows signs of misuse.
 - 4.3. The appliance has signs of overuse.
 - 4.4. The appliance is improperly handled.
 - 4.5. No supporting document (card, ticket or invoice).
 - 4.6. The appliance has not been used in accordance with the instructions for use.

ENVIRONMENT

Meaning of the crossed-out wheeled dustbin:



Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities. Contact your local council for information regarding the collection systems available.

■ If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being.