



AURICULARES INALÁMBRICOS

BOTÓN MULTIFUNCIÓN



MB-EPI24 TWS



ESPECIFICACIONES

- Versión Bluetooth: V5.1
- Formatos Bluetooth soportado: HFP / HSP / A2DP / AVRCP
- Sensibilidad: 105dB $\pm$ 3dB S.P.L. at 1KHz.
- Batería Auricular: 40mAh.
- Batería Base de Carga: 300mAh.

SEGURIDAD AUDITIVA.

- Para evitar lesiones auditivas, no ponga el volumen demasiado alto.
- No use los auriculares durante mucho tiempo sin descanso.

INDICACIONES DE SEGURIDAD.

- Nunca usar los auriculares mientras conduce cualquier vehículo.
- Nunca intente desmontar los auriculares para repararlo usted mismo.
- Mantener siempre secos los auriculares.
- Nunca sumergir en agua ni en otros líquidos.
- Usar siempre en ambientes secos, nunca en ambientes húmedos.
- Trato no adecuado o mal uso, será motivo de anulación de garantía.

CARGA DE LA BASE.

- Cuando la carga de la base es insuficiente, parpadeará la luz indicadora de color verde. Proceder a cargar la batería.
- Conecte el cable Usb-MicroUsb a un adaptador de 5VDC / 2A (max.).
- La luz parpadeará en color rojo mientras está cargando.
- Una vez cargando nunca interrumpa la carga hasta que termine.
- Cuando la luz quede encendida fija, estará completamente cargada.

CARGA DEL AURICULAR.

- Colocar los auriculares en su caja de carga.
- Una vez colocados, empiezan a cargar automáticamente.
- Mientras están cargando permanece encendido un piloto rojo.
- Cuando terminan de cargar el piloto rojo se apaga.

FUNCIONAMIENTO / BOTÓN MULTIFUNCIÓN.

- Sacar los 2 auriculares de la base de carga y esperar a que se vinculen entre ellos. Se encienden automáticamente al sacarlos.
- Para encender o apagar manualmente mantener pulsado 3 segundos el botón multifunción.
- Buscar la referencia "EPI24" en el dispositivo a enlazar con bluetooth.
- Seleccionar y aceptar. Emitirá una señal de conectado.
- Play / Pause: En reproducción tocar una vez para pausar o reanudar.
- Volumen (+): Doble-click en el izquierdo. (-): Doble-click en el derecho.
- Contestar / Colgar llamadas: Click en el izquierdo o derecho.
- Rechazar Llamada: Mantener pulsado en el izquierdo o derecho.
- Marcar Última Llamada: Hacer 3 clicks en el botón del izquierdo.
- Iniciar Asistente de voz: Hacer 3 clicks en el botón del derecho.



WIRELESS EARPHONES

MULTIFUNCTION BUTTON



MB-EPi24 TWS



SPECIFICATIONS

- Bluetooth version: V5.1
- Supported Bluetooth formats: HFP / HSP / A2DP / AVRCP
- Sensitivity: 105dB $\pm$ 3dB S.P.L. at 1KHz.
- Headset Battery: 40mAh.
- Charging Base Battery: 300mAh.

HEARING SAFETY.

- To avoid hearing damage, do not turn the volume too high.
- Do not use the headphones for a long time without rest.

SAFETY INSTRUCTIONS.

- Never use headphones while driving any vehicle.
- Never try to disassemble the headphones to repair it yourself.
- Always keep the headphones dry.
- Never immerse in water or other liquids.
- Always use in dry environments, never in humid environments.
- Improper treatment or misuse, will be grounds for cancellation warranty.

CHARGING THE BASE.

- When the base charge is insufficient, the light will flash green indicator. Proceed to charge the battery.
- Connect the Usb-MicroUsb cable to a 5VDC / 2A (max.) adapter.
- The light will flash red while charging.
- Once charging never interrupt charging until finished.
- When the light stays on steadily, it will be fully charged.

HEADPHONE CHARGING.

- Place the earphones in their charging box.
- Once placed, they start charging automatically.
- While they are charging, a red light stays on.
- When they finish charging the red light goes out.

OPERATION / MULTIFUNCTION BUTTON.

- Take the 2 headphones out of the charging base and wait for them to link between them. They turn on automatically when you take them out.
- To turn it on or off manually, press and hold for 3 seconds the multifunction button.
- Find the reference "EPi24" on the device to be paired with bluetooth.
- Select and accept. It will emit a connected signal.
- Play / Pause: In playback touch once to pause or resume.
- Volume (+): Double-click on the left. (-): Double-click on the right.
- Answer / Hang up calls: Click on the left or right.
- Reject Call: Long press on the left or right.
- Mark Last Call: Make 3 clicks on the left button.
- Start Voice Assistant: Make 3 clicks on the right button.