



MINI TOSTADOR PLANO

TH-MTP115

300W, 220-240V~50Hz

Lea detenidamente el manual antes de usar el producto por primera vez.

Guarde estas instrucciones para futuras consultas.

Estimado cliente:

Agradecemos la confianza depositada en nosotros al adquirir este producto THULOS®. Nuestro principal empeño es ofrecer artículos excelentes, manteniendo los más estrictos controles de calidad y cumpliendo todas las normativas vigentes de seguridad, con el objetivo de presentar un producto perfecto y seguro para el uso doméstico.

Lea detenidamente el presente manual de instrucciones y guárdelo para posterior consulta. En caso de entregar el aparato a terceros, entregue también el presente manual de instrucciones.

CONSEJOS DE SEGURIDAD

Lea cuidadosamente las instrucciones antes Por favor, tenga en cuenta los siguientes consejos para evitar un mal funcionamiento, daño físico o heridas:

- Ignorar estas instrucciones exime al fabricante de cualquier responsabilidad.
- No cumplir este manual será motivo de exención de la garantía.
- Compruebe que la red eléctrica de su casa coincide con la del aparato.
- Este aparato pueden utilizarlo niños con edad de 8 años y superior y personas con capacidades físicas, sensoriales o mentales reducidas o falta de experiencia y conocimiento, si se les ha dado la supervisión o formación apropiadas respecto al uso del aparato de una manera segura y comprenden los peligros que implica. La limpieza y el mantenimiento a realizar por el usuario no deben realizarlo los niños sin supervisión.
- Los niños no deben jugar con el aparato.
- El aparato debe ser utilizado solo para el fin por el que ha sido fabricado.
- Antes de enchufarlo compruebe la corriente.
- No sumerja el aparato en agua o cualquier otro líquido. Si accidentalmente se mojan el aparato o el enchufe desconéctelo inmediatamente y llévelo a que un electricista lo compruebe antes de usarlo nuevamente. Nunca intente abrir el aparato.
- Tenga cuidado ya que el grill superior se calentará mucho durante su uso.
- La parrilla tostadora puede alcanzar una temperatura alta cuando el aparato está en funcionamiento. La temperatura de los paneles de metal en el cuerpo principal también puede ser muy caliente.
- La temperatura de la superficie puede ser alta cuando el aparato está en funcionamiento.
- No use el aparato con las manos húmedas, en un suelo mojado o cuando el aparato esté también mojado.
- No toque el cable con las manos mojadas o húmedas.
- Si el cable está dañado debe ser sustituido por el fabricante o servicio técnico cualificado.
- No utilice el aparato si se ha caído o ha sido dañado de cualquier otra forma o bien si el cable o el enchufe están estropeados. En caso de avería contacte con el fabricante o con el departamento del cliente o lleve el aparato al servicio técnico oficial.
- Nunca intente reparar el aparato usted mismo.

- No deje el cable descansar sobre puntas afiladas y manténgalo lejos de objetos calientes o llamas (hornos de gas). Desenchufe el cable tirando del enchufe nunca del cable.
- Coloque el aparato en un nivel firme y resistente al calor, alejado de las llamas.
- Este aparato no es apto para uso comercial.
- No utilice el aparato al aire libre.
- Nunca deje el aparato desatendido mientras esté funcionando.
- Mantenga el aparato fuera del alcance de los niños.
- Siempre retire el cable del enchufe cuando el aparato no esté encendido o en uso y siempre antes de que vaya a limpiarlo.
- Nunca use el cable para transportar o tirar del aparato.
- No use rebanadas de pan envueltas en papel de aluminio o plástico.
- No conecte el tostador a un temporizador o a un sistema de control remoto.
- El pan puede arder, por lo tanto, no use la tostadora cerca o debajo de materiales combustibles, como cortinas.
- Limpieza y mantenimiento de usuarios no deberán ser realizados por los niños.
- Mantenga el aparato y el cable fuera del alcance de los niños.



COMPONENTES PRINCIPALES

1. Cuerpo principal.
2. Rejilla.
3. Bandeja recogemigas.
4. Interruptor ON/OFF con lámpara piloto.

Funcionamiento

Atención: El pan puede quemarse. Nunca use el tostador cerca o debajo de cortinas u otro material inflamable. Nunca toque el grill superior durante el proceso, se caliente mucho cuando el aparato está en uso.

CÓMO USAR EL TOSTADOR

Antes del primer uso

Antes de usarlo por primera vez, ponga el tostador una sola vez al máximo sin poner ningún pan, para limpiar los elementos de calor. Después de esto el tostador está listo para usarlo.

Tostar pan

- Conecte el aparato a la red.
- Coloque las rebanadas de pan sobre la parrilla de tostado (2).
- NO unte las rebanadas con aceite o mantequilla para tostarlo.
- Voltee manualmente la rebanada de pan cuando vea que se ha tostado por una cara.

Limpieza y mantenimiento

- Limpie el aparato antes del primer uso, inmediatamente después de cada uso y tras un largo periodo de tiempo sin usar.
- Antes de limpiar el tostador, asegúrese de que esta desenchufado de la red y completamente frío.
- Limpie el cuerpo exterior del aparato y la parrilla de tostador con un paño húmedo.
- Extraiga la bandeja recogemigas tirando de ella hacia afuera (3) y limpie las migas, restos de pan, etc.
- Coloque de nuevo la bandeja y asegúrese de que queda colocada correctamente.

Datos Técnicos

- Modelo: TH-MTP115
- Nombre: Mini Tostador Plano
- Voltaje: 220-240V~50Hz
- Potencia: 300W.

MEDIO AMBIENTE

¡Usted también puede contribuir a la conservación del medio ambiente!



Este aparato no debe desecharse con la basura doméstica al final de su vida útil, sino que se debe depositar en un punto de recogida para el reciclaje de aparatos eléctricos y electrónicos. Este símbolo en el aparato, manual de instrucciones y embalaje quiere atraer su atención sobre esta importante cuestión. Los materiales utilizados en este aparato se pueden reciclar. Mediante el reciclaje de electrodomésticos, usted contribuye a fomentar la protección del medioambiente. Solicite más información sobre los puntos de recogida a las autoridades locales.

CONDICIONES DE GARANTÍA

- Este aparato está cubierto contra cualquier defecto de fábrica.
- El aparato se cambiará siempre y cuando esté dentro del plazo.
- De cambio y se devuelva con todos sus accesorios y embalaje.
- La garantía será válida siempre y cuando el aparato vaya acompañado de su factura o ticket de compra donde salga reflejado el aparato,
- O también su tarjeta de garantía debidamente cumplimentada y sellada.
- El aparato estará exento de garantía (no cubierto) cuando:
 - El aparato tenga señales de golpes y/o caídas.
 - El aparato presente signos de mal uso.
 - El aparato presente signos de uso excesivo.
 - El aparato esté manipulado inadecuadamente.
 - No tenga documento acreditativo (tarjeta, ticket o factura compra).
 - El aparato no se ha usado según las instrucciones de uso.

NOTA:

Bajo ningún concepto se hará cambio directo o abono directo sin antes revisar el aparato y las causas por las que se ha averiado.



MINI FLAT TOASTER

TH-MTP115

300W, 220-240V~50Hz

Please read this manual carefully before to use.
Save this manual for future reference.

Dear Customer:

We appreciate the confidence placed in us by purchasing this THULOS® product.

Our main commitment is to provide excellent articles while maintaining the strictest quality controls and compliance with all applicable safety regulations, with the aim of presenting a perfect and safe product for domestic use. Carefully read this manual and keep it for future reference. If the instrument is delivered to third parties, also delivered this instruction manual.

SAFETY NOTES

Please note the following advice to avoid malfunctions, physical damage and injuries:

- Ignoring these instructions exempts the manufacturer from any responsibility.
- Failure to comply with this manual will be grounds for waiver of the warranty.
- Check that your home's electrical current matches that of the appliance.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children must never play with the appliance. Cleaning and user maintenance must never be carried out by children without supervision.
- Children should be supervised to ensure they do not play with the appliance.
- The appliance may be used only for its intended purpose, the appliance is suitable for toasting bread only, but not for grilling chicken, beef and other food.
- Before plugging in the appliance, check that the current and power match those given on the rating plates.
- Do not immerse the appliance in water or any other liquid. If the appliance or plug should accidentally become wet, disconnect the power immediately and have the appliance checked by an electrician before using it again. Never attempt to open the appliance yourself.
- Be careful, the top grill will become very hot during use.
- The temperature of accessible surfaces may be high when the appliance is operating.
- The surfaces are liable to get hot during use.
- Do not use the appliance with wet hands, on a damp floor or when the appliance itself is wet.
- Do not touch the plug with wet or damp hands.
- If the power cord is damaged it must be replaced by the manufacturer or its service agent or a similarly qualified person.
- Do not use the appliance if it has been dropped or otherwise damaged or if the cable or plug are damaged. In the case of damage, contact our customer support department or take the appliance to an electrical repair shop for examination and repair if necessary.
- Never attempt to repair the appliance yourself.
- Do not allow the cable to hang over sharp edges and keep it well away from hot objects and naked flames (e.g. gas oven). Remove the plug from socket only by pulling on the plug, never on the cord.

- Set the appliance on a firm, level and heatproof surface away from naked flames.
- This appliance is not suitable for commercial use.
- Do not use the appliance outdoors.
- Never leave the appliance unattended while it is in use.
- Keep the appliance out of the reach of children.
- Always remove the plug from the socket when the appliance is not in use and each time before it is cleaned.
- Never use the cable to carry the appliance.
- Do not use bread slices which are wrapped in aluminum or plastic foil.
- Appliances are not intended to be operated by means of an external timer or separate remote-control system.
- The bread may burn, therefore do not use the toaster near or below combustible material, such as curtains.
- Children shall not play with the appliance.
- Keep the appliance and its cord out of reach of children.

MAIN COMPONENTS

1. Main body
2. Toaster grill
3. Crumb tray
4. ON/OFF switch



OPERATION

Never touch the grill during operation. It becomes very hot when the appliance is in use. Bread may burn. Never use the toaster near or below curtains or other flammable material.

HOW TO USE THE TOASTER

- Before the first use operate the toaster once on maximum heat without using any bread to clean the heating elements. Thereafter your toaster is ready to be used.

TOAST BREAD

- Plug it into the mains.
- Put slices of bread on the toaster grill (2), switch on.
- DO NOT spread oil or butter on slices of bread before toasting.
- Turn the slice of bread over manually when it is toasted on one side.

CLEANING AND MAINTENANCE

- Clean the appliance before using it for the first time, immediately after each use and after not using it for a long period of time.
- Before cleaning the toaster, make sure it is unplugged from the mains and completely cold.
- Clean the outside of the appliance and toaster grill with a damp cloth.
- Pull out the crumb tray (3) to remove crumbs, bits of bread, etc.
- Place the tray back in place and ensure it is placed correctly.

TECHNICAL DATA

- Model: TH-MTP115
- Name: Mini Flat Toaster
- Rated voltage: 220-240V~50Hz
- Power: 300W.

CLEANING AND MAINTENANCE

- Always unplug before cleaning.
- Remove the collecting tray and empty the dead insects.
- Clean the tray with paper.
- Clean the grilles with a thin hair brush.
- Make sure that the brush does not leave hairs hooked on the grid.
- Never wash with water or damp cloths.
- Store in a cool, dry and dust-free area.

ENVIRONMENT



This appliance should not be put into the domestic garbage at the end of its durability, but must be offered at a central point for the recycling of electric and electronic domestic appliances. This symbol on the appliance, instruction manual and packaging puts your attention to this important issue. The materials used in this appliance can be recycled. By recycling of used domestic appliances you contribute an important push to the protection of our environment. Ask your local authorities for information regarding the point of recollection.

WARRANTY CONDITIONS

1. This appliance is covered against any factory defects.
2. The device is changed for a new one as long as it is within the change period and is returned with all accessories and packaging in good condition.

3. The guarantee will be valid as long as the appliance is accompanied by your invoice or purchase ticket where the exact device and model, or your warranty card duly completed and sealed, is reflected.
4. The appliance will be exempt from warranty when:
 - The appliance has signs of knocks and / or falls.
 - The appliance shows signs of misuse.
 - The appliance has signs of overuse.
 - The appliance is improperly handled.
 - No supporting document. (Card, ticket or invoice).
 - The appliance has not been used in accordance with the instructions for use.

NOTE:

Under no circumstances will direct change or direct payment be made without first reviewing the device and the causes for which it has failed



MINI TOSTADOR PLANO
MINI FLAT TOASTER
TH-MTP115



EAN: 8436550623185

www.thulos.com
thulos@thulos.com

Servicio Técnico / Technical Service: sat@grupothulos.com

