



BÁSCULA DE COCINA



TH-DS109

ESTIMADO CLIENTE

Agradecemos la confianza depositada en nuestra marca THULOS®. Nuestro principal empeño es ofrecer artículos excelentes, manteniendo los más estrictos controles de calidad y cumpliendo todas las normativas vigentes de seguridad, con el objetivo de presentar un producto perfecto y seguro para el uso doméstico.

BATERÍA

- Antes del primer uso, poner primero la pila que viene dentro de la caja.
- Si la báscula no se utiliza durante largos períodos se aconseja quitar la pila.
- Mantenga las pilas y baterías fuera del alcance de los niños.
- Almacenarlas en zonas frescas alejadas de fuentes de calor.
- Nunca mezclar varios tipos de baterías tales como nuevas y gastadas.
- Cuando la batería o pila está baja, en display aparece "o-Ld".
- Reemplace la pila o batería por una nueva cuando aparezca este código.

UBICACIÓN

Para un correcto funcionamiento de la balanza, debe ponerse en una mesa firme, lisa y nivelada. De lo contrario, el peso puede dar lugar a errores.

FUNCIONAMIENTO

- Poner la balanza en una superficie lisa, nivelada y firme.
- Para encender, mantener pulsado el botón "ON/TARE".
- Esperar a que aparezca "0" en el display.
- Si necesita utilizar la función TARA, pulse el botón "ON/TARE".
- Utilice esta función para añadir alimentos a un mismo recipiente.
- Para cambiar de unidad de medida pulse el botón "UNIT".
- Para apagar puede esperar un minuto sin tocarla ni peso encima.
- Para apagar también puede mantener pulsado el botón "ON/TARE".

ESPECIFICACIONES

MODELO	MEDIDAS	ESPECIFICACIONES
TH-DS109	203x153x17 mm.	<ul style="list-style-type: none">- 4 SENSORES DE PRECISIÓN.- PESO MÁXIMO: HASTA 5KG.- GRADUACIÓN: 1G.- UNIDADES DE PESO: G / LB:OZ / KG- MIDE EL VOLUMEN DE AGUA Y LECHE (ML).- FUNCIÓN TARA.- INDICADOR BATERÍA BAJA Y SOBRECARGA.



KITCHEN SCALE



TH-DS109

DEAR CUSTOMER.

We appreciate the trust placed in us when purchasing this THULOS® product. Our main effort is to offer excellent items, maintaining the strictest quality controls and complying with all current safety regulations, in order to present a perfect and safe product for domestic use.

BATTERY.

- Before first use, first put the battery that comes inside the box.
- If the scale is not used for long periods, it is advisable to remove the battery.
- Keep batteries and batteries out of the reach of children.
- Store them in cool areas away from heat sources.
- Never mix several types of batteries such as new and worn.
- When the battery is low, "o-Ld" appears on the display.
- Replace the battery or battery with a new one when this code appears.

LOCATION.

For a correct operation of the balance, it must be placed on a table firm, smooth and level. Otherwise, the weight can lead to errors.

OPERATION.

- Put the balance on a smooth, level and firm surface.
- To turn on, press and hold the "ON / TARE" button.
- Wait until "0" appears in the display.
- If you need to use the TARE function, press the "ON / TARE" button.
- Use this function to add food to the same container.
- To change the unit of measurement press the "UNIT" button.
- To turn off you can wait a minute without touching it or weight on top.
- To turn off you can also keep the "ON / TARE" button pressed.

SPECIFICATIONS.

MODEL	MEASURES	SPECIFICATIONS
TH-DS109	203x153x17 mm.	<ul style="list-style-type: none"> 4 PRECISION SENSORS. MAXIMUM WEIGHT: UP TO 5Kg. GRADUATION: 1g. WEIGHT UNITS: G / LB:OZ / KG. MEASURE VOLUME OF WATER AND MILK. TARA FUNCTION. LOW BATTERY INDICATOR. OVERLOAD INDICATOR.