



PIMENTERO Y SALERO ELÉCTRICO 2EN1



IDEAL PARA
SAL-PIMENTAR
CARNES, PESCADOS
Y GUISOS CON
SOLO APRETAR
UN BOTÓN

MANUAL DE INSTRUCCIONES TH - PM002

Lea atentamente este manual antes de usar este aparato por primera vez.
Guarde el manual para futuras consultas.
Si vende ó presta el aparato a terceros, debe ir acompañado de este manual.

INTRODUCCIÓN

Estimado cliente

Agradecemos la confianza depositada en nosotros al adquirir este producto THULOS®. Nuestro principal empeño es ofrecer artículos excelentes, manteniendo los más estrictos controles de calidad y cumpliendo todas las normativas vigentes de seguridad, con el objetivo de presentar un producto perfecto y seguro para el uso doméstico.

DIAGRAMA DE LOS COMPONENTES



1. Tapa superior.
2. Botones de sal y pimienta.
3. Carcasa del motor y compartimento para las baterías (6xAAA no incluidas).
4. Depósito transparente.
5. Molinillo de cerámica.
6. Ajuste del nivel de grosor.
7. Cubierta inferior

CUBIERTA INFERIOR DE DOBLE FUNCIÓN



Función 1:
Tapadera inferior para
Evitar la salida de
residuos



Función 2:
Embudo de llenado



Nota: Retire la
cubierta inferior
cuando use el
molinillo.

INSTALACIÓN DE LAS BATERÍAS

- Para quitar la tapa superior, gírela en sentido anti horario y levántela hacia arriba.
- Levante la unidad de alimentación e instale 6 baterías AAA.
- Al poner las baterías, especial atención en los polos positivos (+) y negativos (-).
- No deje las baterías descargadas en el aparato.
- Siempre reemplace las 6 baterías al mismo tiempo.
- Usar siempre baterías alcalinas.
- Nunca mezclar baterías de distinta marca y tampoco mezclar nuevas y usadas.
- Se recomienda usar siempre baterías alcalinas.

RELLENADO DEL DEPÓSITO

- Retire la cubierta inferior y colóquela en el depósito transparente, como un embudo de llenado.
- Utilice el medio orificio conmutable de la cubierta inferior como embudo para llenar el depósito de sal o pimienta.
- Deje algo de espacio en las cámaras transparentes para evitar atascos.

NOTA:

Colocar los granos de pimienta en el recipiente izquierdo y la sal en el recipiente derecho.

FUNCIONAMIENTO

- Montar el molinillo.
 - Asegúrese de que la muesca cuadrada de la unidad del motor se conecta con el eje de transmisión.
 - Coloque la tapa superior en la unidad de potencia y gírela suavemente hacia la derecha.
 - Presione el botón izquierdo o derecho, saldrá la pimienta o la sal molida.
 - Si la máquina se atasca durante el uso, agite suavemente la unidad.
- Es normal que los granos de pimienta o la sal se atasquen ocasionalmente en el molinillo.

AJUSTE DEL GROSOR

- Para un molido más fino:
Gire la tuerca de ajuste debajo de la cámara en el sentido de las agujas del reloj.
- Para un molido más grueso:
girar la tuerca de ajuste en el sentido contrario a las agujas del reloj.

ADVERTENCIAS

- No presione ambos botones al mismo tiempo.
- Llene el depósito transparente al 50%, demasiados granos pueden atascar el mecanismo.
- Nunca apriete completamente la tuerca de ajuste del nivel de grosor del molido.
- **¡Usar solamente sal de mar!** La sal de roca dañará el mecanismo y anulará la garantía.
- Limpie el exterior del aparato con un paño suave y húmedo. Nunca sumergir en agua.
- Este aparato no es apto para utilizar por niños ni personas con alguna discapacidad.
- Este aparato no es un juguete para niños.
- Mantenga el aparato fuera del alcance de los niños bajo su total responsabilidad.
- Almacenar en lugar limpio y seco.

ESPECIFICACIONES

- Alimentación por baterías (pilas).
- Baterías: 6x1'5V AAA.
- Tamaño: 17cmX6.8cm
- Molinillo de cerámica.
- Material exterior: acero inoxidable + AS.
- Se usa para moler sal y pimienta.

CONDICIONES DE GARANTÍA.

1. ESTE APARATO ESTA CUBIERTO CONTRA CUALQUIER DEFECTO DE FÁBRICA.
2. EL APARATO SE CAMBIARÁ SIEMPRE Y CUANDO ESTÉ DENTRO DEL PLAZO DE CAMBIO Y SE DEVUELVA CON TODOS SUS ACCESORIOS Y EMBALAJE.
3. LA GARANTÍA SERÁ VÁLIDA SIEMPRE Y CUANDO EL APARATO VAYA ACOMPAÑADO DE SU FACTURA Ó TICKET DE COMPRA DONDE SALGA REFLEJADO EL APARATO, Ó TAMBIÉN SU TARJETA DE GARANTÍA DEBIDAMENTE CUMPLIMENTADA Y SELLADA.
4. EL APARATO ESTARÁ EXENTO DE GARANTÍA (NO CUBIERTO) CUANDO:
 - EL APARATO TENGA SEÑALES DE GOLPES Y/O CAÍDAS.
 - EL APARATO PRESENTE SIGNOS DE MAL USO.
 - EL APARATO PRESENTE SIGNOS DE USO EXCESIVO.
 - EL APARATO ESTÉ MANIPULADO INADECUADAMENTE.
 - NO TENGA DOCUMENTO ACREDITATIVO (TARJETA, TICKET Ó FACTURA COMPRA).
 - EL APARATO NO SE HA USADO SEGÚN LAS INSTRUCCIONES DE USO.

NOTA:

- **BAJO NINGÚN CONCEPTO SE HARÁ CAMBIO DIRECTO Ó ABONO DIRECTO**
SIN ANTES REVISAR EL APARATO Y LAS CAUSAS POR LAS QUE SE HA AVERIADO.

NORMAS DE PROTECCIÓN DEL MEDIO AMBIENTE



Este aparato no se debe desechar con los residuos domésticos cuando finalice su durabilidad, sino que se debe ofrecer a un centro de reciclaje de aparatos eléctricos y electrónicos domésticos. Este símbolo en el aparato, manual de instrucciones y embalaje le avisa de este aspecto importante.

Los materiales utilizados en este aparato se pueden reciclar. Mediante el reciclaje de electrodomésticos, usted contribuye a fomentar la protección del medioambiente. Consulte a sus autoridades locales para obtener información acerca del punto de recogida.



ELECTRIC PEPPER & SALT MILL 2in1



INSTRUCTIONS MANUAL TH - PM002

Read this manual carefully before using this device for the first time.
Save the manual for future reference.

If you sell or lend the device to third parties, it must be accompanied by this manual.

INTRODUCTION

Dear Customer

We appreciate the trust placed in us when purchasing this THULOS® product.

Our main commitment is to offer excellent items, maintaining the strictest quality controls and complying with all current safety regulations, in order to present a perfect and safe product for domestic use.

DIAGRAM OF THE COMPONENTS



1. Upper cap.
2. Salt and pepper buttons.
3. Motor housing and 6 "AAA" battery compartment (batteries not included)
4. Clear chamber.
5. Ceramic grinder.
6. Adjusting nut.
7. Bottom cover (dual functions: a mess-free bottom lid and a filling funnel)

DUAL FUNCTION BOTTOM COVER



Function1:
Mess free bottom lid on table.



Function 2:
Fillingfunnel.



Note: remove the bottom coverwhen you run the mill.

BATTERY INSTALLATION.

- To remove the top cover, turn it counterclockwise and lift it up.
- Lift the power unit and install 6 AAA batteries.
- When putting the batteries, pay special attention to the positive (+) and negative (-) poles.
- Do not leave the discharged batteries in the device.
- Always replace all 6 batteries at the same time.
- Always use alkaline batteries.
- Never mix batteries of different brands and do not mix new and used ones.
- It is recommended to always use alkaline batteries.

RE-FILLING THE DEPOSIT

- Remove the bottom cover and place it in the transparent tank, as a filling funnel.
- Use the switchable half hole of the bottom cover as a funnel to fill the tank salt or pepper
- Leave some space in the transparent chambers to avoid jams.

NOTE:

Place the peppercorns in the left bowl and salt in the right bowl.

OPERATION

- Mount the grinder.
 - Make sure that the square notch of the motor unit is connected to the drive shaft.
 - Place the top cover on the power unit and turn it gently to the right.
 - Press the left or right button, the pepper or ground salt will come out.
 - If the machine gets stuck during use, gently shake the unit.
- It is normal for peppercorns or salt to occasionally get stuck in the grinder.

THICKNESS ADJUSTMENT

- For a finer ground:
Turn the adjusting nut under the camera clockwise.
- For a coarser grind:
turn the adjusting nut counterclockwise.

WARNINGS

- Do not press both buttons at the same time.
- Fill the transparent tank to 50%, too many grains can clog the mechanism.
- Never fully tighten the nut for adjusting the grind thickness level.
- Use only sea salt! Rock salt will damage the mechanism and void the warranty.
- Clean the outside of the appliance with a soft damp cloth. Never immerse in water.
- This device is not suitable for use by children or people with disabilities.
- This device is not a toy for children.
- Keep the device out of reach of children under your total responsibility.
- Store in a clean and dry place.

SPECIFICATIONS

- Battery power (batteries).
- Batteries: 6x1'5V AAA.
- Size: 17cmX6.8cm
- Ceramic grinder.
- External material: stainless steel + AS.
- It is used to grind salt and pepper.

WARRANTY CONDITIONS.

1. This appliance is covered against any factory defects.
2. The device is changed for a new one as long as it is within the change period and is returned with all accessories and packaging in good condition.
3. The guarantee will be valid as long as the appliance is accompanied by your invoice or purchase ticket where the exact device and model, or your warranty card duly completed and sealed, is reflected.
4. THE APPLIANCE WILL BE EXEMPT FROM WARRANTY WHEN:
 - The appliance has signs of knocks and / or falls.
 - The appliance shows signs of misuse.
 - The appliance has signs of overuse.
 - The appliance is improperly handled.
 - No supporting document. (Card, ticket or invoice).
 - The appliance has not been used in accordance with the instructions for use.

NOTES.

- **Under no circumstances will direct change or direct payment be made** without first reviewing the device and the causes for which it has failed.

GUIDELINES FOR PROTECTION OF THE ENVIRONMENT



This appliance should not be put in to the domestic garbage at the end of its durability, but must be offered at a central point for there cycling of electric and electronic domestic appliances. This symbol on the appliance, instruction manual and pack again put your attention to this important issue.

The materials used in this appliance can be recycled. By recycling of used domestic appliances you contribute important push to the protection of our environment. Ask your local authorities for information regarding the point of recollection.



2 EN 1: PIMENTERO Y SALERO ELÉCTRICO / 2 IN 1: ELECTRIC PEPPER& SALT MILL
TH-PM002



EAN: 8436572768185

www.thulos.com

thulos@thulos.com

Servicio Técnico/TechnicalService:

sat@thulos.com