

CONSEJOS

Responsabilidad:

El montaje o la instalación inadecuados pueden provocar lesiones. También puede dañar al aparato o su TV con un montaje inadecuado. Lea este manual de instalación detenidamente antes de la instalación.



1. El producto debe ser instalado por profesionales.
2. Si no entiende, comuníquese con un instalador local calificado.
3. Si el producto esta defectuoso o faltan accesorios, no lo instale. Póngase en contacto con el establecimiento donde lo ha comprado.
4. Este producto es adecuado para pantallas de plasma / LCD de 14"-42" y puede soportar hasta un máximo de 35 kg.
5. Este producto se utiliza en columnas de paredes de madera maciza o paredes macizas.
6. Por razones de seguridad, confirme que la pared donde va a instalar el producto debe soportar el peso combinado del televisor, el soporte y los accesorios tres veces más.
7. Este producto solo se puede usar para esta función, no lo use para otros propósitos. El fabricante no se hace responsable de usos inadecuados.
8. El fabricante no será responsable de los daños a la vertical. pared causada por carga accidental o descargada.
9. El fabricante declara por la presente que no es responsable de ningún daño o daño causado por la instalación que no cumpla con los requisitos de responsabilidad.

move with


MOBIL 

SOPORTE PARA TV

MB-TVB4235




1



-  Nivel Burbuja
-  Taladro
-  Lápiz
-  Broca 10mm

Sostener la placa a la pared y poner el nivel encima para nivelar. Una vez la burbuja en el centro marcar con el lápiz en la pared los orificios.


2



- A**  Ø10X50mm 4PCS
- B**  M6X45mm 4PCS
- C**  Ø16XØ6X1.5mm 4PCS

- Hacer los taladros en las marcas señaladas en la pared.
- Introducir los tacos (A) en los orificios de la pared.
- Atornillar la placa a la pared con los tornillos (B) y (C).

3



- D**  M4*10 4PCS
-  M5*10
-  M6*10



- E**  M5*35 2PCS

- Montar los anclajes a los perfiles.

- Montar los perfiles a la TV.

- Prestar atención a la longitud de los tornillos a la TV. Si son demasiado largos utilizar espaciadores.

4





- Anclar la TV a la placa de la pared haciendo entrar a las ranuras superiores y después las inferiores.

- Asegurar los anclajes poniendo un tornillo entre anclaje y placa de la pared.


TIPS!

Disclaimer:improper assembly or installation may result in injury or death, destruction of property.Please read this installation manual carefully before installation Information.

1. The product must be installed by professionals.
2. If you do not understand, please contact a qualified local installer.
3. If the product is abnormal or missing, please do not assemble or install it. Please contact the local dealer get help.
4. This product is suitable for 14"-42" LCD/plasma screen, and can bear 35kg / 77lbs.
5. This product is used on solid wood wall column or solid wall.
6. For safety reasons, please confirm that the wall of the installation product should bear the combined weight of the TV set, bracket and accessories three times as much.
If the expansion tube on the wall is found to be loose during installation, please stop the installation.
7. This product can only be used for display in this range, please do not use for other purposes.
8. The manufacturer shall not be responsible for the damage to the vertical wall caused by unloaded or accidental load.
9. The manufacturer hereby declares that it is not liable for any damage or damage caused by the installation not in accordance with the requirements responsibility.




1



- Bubble Level
- Electric Drill
- Pencil
- Drill

1.Stick a pencil in the wall According to the product installation board Installation Draw points on the holes and drill them into place Hole.


2



- A Expansion pipe 4PCS
- B Self-tapping screws 4PCS
- C Gasket 4PCS

2. Put the expansion pipe (A) into the installation hole of the wall. Self-tapping screws (B) Fix the product mounting plate to the wall through the gasket (C)


3



- D M4*10 4PCS
- E M5*35 2PCS

3.Fix the TV set in the mounting position with round head screw (D) On a board. Twist the safety screw (E) onto the hook

4



4. Hang the TV hook on the bracket and lock it tightly The safety screw is installed

