



LIMADOR DE DUREZAS

TH-BY09

ESPECIFICACIONES

- 2 Rodillos (Fino / Grueso).
- Luz Led.
- Batería Recargable.
- 2 velocidades.



ADVERTENCIAS POR Y PARA SU SEGURIDAD

- Mantener seco el aparato en todo momento.
- No usar en zonas con ambiente húmedo.
- No pueden usarlo niños ni personas con capacidades reducidas que no entiendan su funcionamiento y riesgos.
- Este aparato no es un juego para niños.

- Solamente puede ser reparado por un servicio técnico autorizado.
- Mantener constante supervisión mientras esté enchufado cargando.
- Nunca sumergir en agua u otro líquido ninguna de las partes.
- No dar golpes al aparato.
- No usar con accesorios no recomendados por el fabricante.
- Mantener siempre limpio el aparato.
- Siempre desenchufar el cargador cuando termine de cargarlo.
- Si no va a usarlo durante un largo tiempo, cargar la batería.
- La marca se exime de cualquier responsabilidad por accidentes y/o averías causados por incumplimiento de estas instrucciones.

FUNCIONAMIENTO.

- Primero de todo hay que cargar la batería completamente.
- Asegurarse de que los pies están limpios y bien secos.
- Asegurarse de que el rodillo está bien colocado.
- Seleccionar la velocidad deseada con el interruptor (2 velocidades).
- No apretar el rodillo contra la piel, suficiente con tocar la piel.
- Hacer movimientos lentos y pausados sobre toda la zona a limar.
- Si siente dolor o molestia, dejar de usar inmediatamente.
- Verificar si ha limado toda la dureza acumulada.
- Apagar la máquina y limpiar posibles restos de piel en el rodillo.
- Limpiar con un paño seco toda la superficie de la máquina.
- Guardar a ser posible en su caja y en zona seca libre de polvo.

CONSEJOS.

- Usar sobre piel limpia y seca. No usar agua, jabón ni cremas.
- Usar sobre una toalla ya que puede salpicar restos de piel seca.
- Empezar siempre a velocidad baja y después subir si es necesario.
- No forzar el rodillo contra la piel, es suficiente tocando la piel.
- Utilizar el rodillo fino para durezas blandas y/o pequeñas.
- Utilizar el rodillo grueso para durezas duras y/o voluminosas.
- Para cambiar de rodillo hacerlo siempre con la máquina parada.
- No dar golpes a la máquina ni la trate bruscamente.



CALLUS REMOVER

TH-BY09



SPECIFICATIONS

- 2 Rollers (Fine / Coarse).
- Led light.
- Rechargeable battery.
- 2 speeds.



WARNINGS BY AND FOR YOUR SAFETY

- Keep the device dry at all times.
- Do not use in areas with a humid environment.
- Cannot be used by children or people with reduced capacities who do not understand its operation and risks.
- This appliance is not a game for children.

- It can only be repaired by an authorized technical service.
- Maintain constant supervision while plugged in charging.
- Never immerse any of the parts in water or any other liquid.
- Do not hit the device.
- Do not use with accessories not recommended by the manufacturer.
- Always keep the device clean.
- Always unplug the charger when you finish charging it.
- If you are not going to use it for a long time, charge the battery.
- The brand disclaims any liability for accidents and/or breakdowns caused by non-compliance with these instructions.

OPERATION.

- First of all you have to fully charge the battery.
- Make sure the feet are clean and dry.
- Make sure that the roller is correctly positioned.
- Select the desired speed with the switch (2 speeds).
- Do not press the roller against the skin, just touch the skin.
- Make slow and deliberate movements over the entire area to be filed.
- If you feel pain or discomfort, stop using immediately.
- Check if all the accumulated hardness has been filed off.
- Turn off the machine and clean any skin remains on the roller.
- Clean the entire surface of the machine with a dry cloth.
- Store if possible in its box and in a dry, dust-free area.

TIPS.

- Use on clean and dry skin. Do not use water, soap or creams.
- Use on a towel as it can splash traces of dry skin.
- Always start at low speed and then increase if necessary.
- Do not force the roller against the skin, touching the skin is enough.
- Use the fine roller for soft and/or small calluses.
- Use the thick roller for hard and/or voluminous calluses.
- To change the roller, always do it with the machine stopped.
- Do not hit the machine or treat it roughly.