



LIMPIA POROS FACIAL
Pore Cleaning Device
TH-BY01

Por favor, lea cuidadosamente este manual antes de usar el dispositivo por primera vez.
Guarde el manual para futuras consultas.

*For you safety and continued enjoyment of this product.
Always read the instruction book carefully before using*

Estimado cliente:

Agradecemos la confianza depositada en nosotros al adquirir este producto THULOS®. Nuestro principal empeño es ofrecer artículos excelentes, manteniendo los más estrictos controles de calidad y cumpliendo todas las normativas vigentes de seguridad, con el objetivo de presentar un producto perfecto y seguro para el uso doméstico. Lea detenidamente el presente manual de instrucciones y guárdelo para posterior consulta. En caso de entregar el aparato a terceros, entregue también el presente manual de instrucciones.


ADVERTENCIAS

- Before use, talk to your doctor if you have any medical issues or concerns.
- This product is not for use by children.
- Do not wear necklaces, earrings or any facial jewelry while using this product.
- Necklaces, earrings and other types of jewelry should be removed before using this product.
- This product is not for use on areas of the body that have undergone any sort of surgery or have any scars.
- If you experience pain while using this product, discontinue use immediately.
- This product is not waterproof and should not be used in the shower or any situation that involves water.
- Do not store this product in the bathroom or a room that has high moisture content.
- Do not operate in the presence of explosives and/or other flammable fumes or liquids.
- Do not store or use this product near sources of heat or fire.

ATENCIÓN

MANTENGA LAS BATERÍAS LEJOS DE LOS NIÑOS, SON NOCIVAS SI SE INGIEREN

COMPONENTES



CABEZAL PEQUEÑO



Succión suave, perfecta para el uso diario. Bueno para usar en piel sensible y área de la nariz.

CABEZAL GRANDE



Succión fuerte, perfecto para puntos negros.
Nota: No debe usarse alrededor del área de los ojos

CABEZAL OVAL



Abertura ovalada para acceder a las comisuras de la nariz y la boca, y para la piel sensible alrededor de los ojos.

CABEZAL SÓNICO



Ayuda a exfoliar la piel muerta mientras elimina la suciedad y la grasa de la piel.

Nota:

Para piel seca: Una vez a la semana.

Para pieles grasas / mixtas: Dos veces por semana.

No más de 5 minutos al día.

INSTALACIÓN DE LAS BATERÍAS




Figure A


1. Abra la tapa del compartimento de las baterías (Figure A).




Figure B

2. Inserte 2*AA baterías (no incluidas) en el compartimento de la batería. Asegúrese de alinear las marcas (+) y (-) de la batería con las marcas (+) y (-) en el interior del compartimento de la batería (Figura B)

CAMBIAR LOS CABEZALES DE SUCCIÓN




1. Coloque una mano en el cabezal de succión y la otra mano en la unidad (Figura C).




2. Tire firmemente del cabezal de succión y vuelva a instalar el cabezal de succión deseado de la misma manera (Figura D).


USO



- 1 Comience abriendo los poros lavándose la cara con agua tibia, vapor o una toalla caliente y húmeda (Figura E). Asegúrese de secar completamente la cara y las manos antes de pasar al siguiente paso.



- 2 Seleccione el cabezal de succión deseado (consulte el apartado “Cambiar los cabezales de succión”). El dispositivo se enciende deslizando el interruptor de ENCENDIDO / APAGADO hacia arriba. La posición media para succión baja y la posición superior es para succión alta (Figura F).




3 Apply the Pore Cleaner to your face (Figure G) slowly move the device around your face, not keeping it on one place for more than 2 seconds. For best results, focus on your problem areas. NOTE: DO NOT move back and forth in same direction.

CONSEJOS ÚTILES

- Después de usar el limpiador de poros, asegúrese de aplicar un hidratante en el área tratada.
- Antes y después del uso, no use exfoliantes faciales u otros productos exfoliantes.
- No aplique ninguna fuerza hacia abajo durante el uso, las capacidades de succión del dispositivo son suficientes para limpiar sus poros de manera eficiente.
- Un ligero enrojecimiento es normal y desaparecerá después de aproximadamente 30 minutos.

LIMPIEZA



Después de cada uso, limpie el cabezal de succión con agua tibia (Figura H) y deje que el cabezal de succión se seque al aire. No intente limpiar la unidad principal bajo el agua. Limpie la unidad con un paño suave y húmedo.

CONDICIONES DE GARANTÍA

1. Este aparato está cubierto contra cualquier defecto de fábrica.
2. El aparato se cambiará siempre y cuando esté dentro del plazo de cambio y se devuelva con todos sus accesorios y embalaje.
3. La garantía será válida siempre y cuando el aparato vaya acompañado de su factura o

ticket de compra donde salga reflejado el aparato, o también su tarjeta de garantía debidamente cumplimentada y sellada.

4. EL APARATO ESTARÁ EXENTO DE GARANTÍA (NO CUBIERTO) CUANDO:

- 4.1. El aparato tenga señales de golpes y/o caídas.
- 4.2. El aparato presente signos de mal uso.
- 4.3. El aparato presente signos de uso excesivo.
- 4.4. El aparato esté manipulado inadecuadamente.
- 4.5. No tiene documento acreditativo (tarjeta, ticket o factura compra).
- 4.6. El aparato no se ha usado según las instrucciones de uso.

NORMAS DE PROTECCIÓN DEL MEDIOAMBIENTE



Este aparato no se debe desechar con los residuos domésticos cuando finalice su durabilidad, sino que se debe ofrecer a un centro de reciclaje de aparatos eléctricos y electrónicos domésticos. Este símbolo en el aparato, manual de instrucciones y embalaje le avisa de este aspecto importante. Los materiales utilizados en este aparato se pueden reciclar. Mediante el reciclaje de electrodomésticos, usted contribuye a fomentar la protección del medioambiente. Consulte a sus autoridades locales para obtener información acerca del punto de recogida.

Dear Customer:

We thank you very much for having purchased this THULOS® product. We kindly ask you to read and save this instruction manual. Please read these operating instructions carefully and keep them in a safe place. If you pass the unit on to someone else, please give them these operating instructions as well.


WARNING

- Before use, talk to your doctor if you have any medical issues or concerns.
- This product is not for use by children.
- Do not wear necklaces, earrings or any facial jewelry while using this product.
- Necklaces, earrings and other types of jewelry should be removed before using this product.
- This product is not for use on areas of the body that have undergone any sort of surgery or have any scars.
- If you experience pain while using this product, discontinue use immediately.
- This product is not waterproof and should not be used in the shower or any situation that involves water.
- Do not store this product in the bathroom or a room that has high moisture content.
- Do not operate in the presence of explosives and/or other flammable fumes or liquids.
- Do not store or use this product near sources of heat or fire.

WARNING

KEEP BATTERIES AWAY FROM CHILDREN HARMFUL IF SWALLOWED

PRODUCT COMPONENTS



SMALL HEAD



Gentle suction, perfect for everyday use. Good for use on sensitive skin and nose area.

LARGE HEAD



Strong suction, perfect for blackheads. Note: Not for use around the eye area.

OVAL HEAD



Oval opening for getting into corners of nose and mouth, and for sensitive skin around eyes.

SONIC HEAD



Helps exfoliate dead skin while pulling dirt & oil from skin.

Note:

For Dry Skin – Once a week.

For Oily/Mixed Skin – Twice a week.

No more than 5 minutes a day.

BATTERY INSTALLATION




Figure A

3. Open the battery cover (Figure A).



Figure B

4. Insert 2*AA batteries (not included) into the battery compartment. Make sure to line up the (+) and (-) markings on the battery with the (+) and (-) markings on the inside of the battery compartment (Figure B).

HOW TO CHANGE THE SUCTION HEADS




Figure C




Figure D

3. Place one hand on the suction head and your other hand on the unit (Figure C)

4. Firmly pull off the suction head and reinstall your desired suction head in the same manner (Figure D)

HOW TO USE




Figure E




Figure F

- 3 Start by opening up your pores by washing your face with warm water, steam or a hot wet towel (Figure E). Make sure to dry face and hands completely before moving onto the next step.

- 4 Select your desired suction head (see "How to change the suction heads"). The device is turned on by sliding the ON/OFF switch up. The middle position is Low suction and the top position is High suction (Figure F).





Figure G

3 Apply the Pore Cleaner to your face (Figure G) slowly move the device around your face, not keeping it on one place for more than 2 seconds. For best results, focus on your problem areas. NOTE: DO NOT move back and forth in same direction.

HELPFUL TIPS

- After use the Pore Cleaner make sure to apply moisturizer to the treated area.
- Before and after use, do not use any facial scrubs or other exfoliating products.
- Do not apply any downward force during use, the suction capabilities of the device are enough to clean your pores efficiently.
- Slight redness is normal and will disappear after approximately 30 minutes.

HOW TO CLEAN



After each use, clean the suction head by running under warm water (Figure H) allow the suction head to air dry. Do not attempt to clean the main unit by running under water. The clean the main unit, wipe down a soft damp cloth.

WARRANTY CONDITIONS

1. This appliance is covered against any factory defects.
2. The device is changed for a new one as long as it is within the change period and is returned with all accessories and packaging in good condition.
3. The guarantee will be valid as long as the appliance is accompanied by your invoice or purchase ticket where the exact device and model, or your warranty card duly completed and sealed, is reflected.
4. THE APPLIANCE WILL BE EXEMPT FROM WARRANTY WHEN:
 - 4.1. The appliance has signs of knocks and / or falls.
 - 4.2. The appliance shows signs of misuse.
 - 4.3. The appliance has signs of overuse.
 - 4.4. The appliance is improperly handled.
 - 4.5. No supporting document. (Card, ticket or invoice).
 - 4.6. The appliance has not been used in accordance with the instructions for use.

GUIDELINES FOR PROTECTION OF THE ENVIRONMENT



This appliance should not be put in to the domestic garbage at the end of its durability, but must be offered at a central point for there cycling of electric and electronic domestic appliances. This symbol on the appliance, instruction manual and pack again put your attention to this import and tissue.

The materials used in this appliance can be recycled. By recycling of used domestic appliances, you contribute important push to the protection of our environment. Ask your local authorities for information regarding the point of recollection.



LIMPIA POROS FACIAL
Pore Cleaning Device
TH-BY01



EAN: 8436588770981

www.thulos.com

thulos@thulos.com

Servicio Técnico / Technical Service:

sat@grupothulos.com

