



By THULOS

MANDO COMPATIBLE CON TV LG

MOD: TH-IS8007

Gracias por haber elegido un mando a distancia MOBILE + by THULOS.
Conserve este manual para su consulta en el futuro.

CONFIGURACIÓN DEL MANDO A DISTANCIA

El mando a distancia, después de insertar las pilas, normalmente está listo para usar ya que está activado de fábrica con un código específico, capaz de controlar un televisor digital de la marca LG.

El mando a distancia MOBILE + by THULOS reproduce señales infrarrojas correspondientes al original. Las funciones que usan radiofrecuencia (por ejemplo, comandos de voz y punteros) no son compatibles.

Este mando a distancia dispone de memoria permanente, no pierde la configuración aunque las pilas estén descargadas.

COLOCACIÓN DE LAS PILAS

El mando a distancia necesita 2 pilas (AAA) que no se incluyen en el envase.

Introduzca las pilas respetando la polaridad correcta.

Asegúrese de alinear los polos + y - de las pilas con las marcas + - del compartimento de las mismas.

Antes de reemplazar las pilas, tenga preparadas las pilas nuevas. Abra la tapa del compartimento de las pilas, e inserte dos pilas.

Se recomienda no dejar insertadas las pilas que se han agotado, podrían perder líquido y dañar el mando a distancia.

¡ATENCIÓN! Muchos problemas suelen estar causados por la carga insuficiente de las pilas. Se recomienda verificar y sustituirlas.

¡ATENCIÓN! Para obtener asistencia técnica es indispensable indicar la MARCA y el MODELO del aparato que desea controlar y el nombre del mando a distancia MOBILE + by THULOS que está utilizando.

GARANTÍA: Conserve el ticket de compra como prueba de validez de la garantía. La manipulación y el uso impropio del producto anulan la garantía.

Nota Informativa: Todos los nombres, marcas o fotos comerciales son propiedad de sus respectivos titulares y están citados únicamente a título de referencia. Nuestro mando no es original de LG y NO está diseñado, fabricado, aprobado, patrocinado o respaldado por LG.

	<p>ADVERTENCIA DE SEGURIDAD</p> <p>El mando a distancia y las pilas no deben exponerse a calor excesivo, como la luz del sol, fuego o similar</p> <p>El producto no es un juguete; no dejarlo al alcance de los niños ni los animales domésticos.</p>
---	---





REMOTE CONTROL

COMPATIBLE WITH

LG TV

MOD: TH-IS8007

Thank you for choosing a MOBILE + by THULOS remote control.
Please keep this manual for future reference.

REMOTE CONTROL SETUP

After inserting the batteries, the remote control is usually ready to use as it is factory-activated with a specific code capable of controlling a LG brand digital TV.

The MOBILE + by THULOS remote control reproduces infrared signals corresponding to the original. Functions using radio frequency (e.g., voice commands and pointers) are not compatible.

This remote control has permanent memory; it does not lose its settings even if the batteries are discharged.

BATTERY INSTALLATION

The remote control requires 2 batteries (AAA) which are not included in the package.

Insert the batteries respecting the correct polarity.

Ensure that the + and - poles of the batteries align with the + - marks in the battery compartment.

Before replacing the batteries, have the new ones ready. Open the battery compartment cover and insert two batteries.

It is recommended not to leave exhausted batteries inside, as they could leak liquid and damage the remote control.

ATTENTION! Many problems are often caused by insufficient battery charge. It is recommended to check and replace them.

ATTENTION! To obtain technical assistance, it is essential to indicate the BRAND and MODEL of the device you wish to control and the name of the MOBILE + by THULOS remote control you are using.

WARRANTY: Keep the purchase receipt as proof of warranty validity. Tampering with or improper use of the product voids the warranty.

Informative Note: All commercial names, brands, or photos are the property of their respective owners and are cited solely for reference purposes. Our remote is not an original LG product and is NOT designed, manufactured, approved, sponsored, or endorsed by LG.

	<p>SAFETY WARNING</p> <p>The remote control and batteries must not be exposed to excessive heat, such as sunlight, fire, or similar.</p> <p>The product is not a toy; do not leave it within reach of children or pets.</p>
---	---

