

CONSEJOS




Responsabilidad:

El montaje o la instalación inadecuados pueden provocar lesiones. También puede dañar al aparato o su TV con un montaje inadecuado. Lea este manual de instalación detenidamente antes de la instalación.

1. El producto debe ser instalado por profesionales.
2. Si no entiende, comuníquese con un instalador local calificado.
3. Si el producto está defectuoso o faltan accesorios, no lo instale. Póngase en contacto con el establecimiento donde lo ha comprado.
4. Este producto es adecuado para pantallas de plasma / LCD de 26"-55" y puede soportar hasta un máximo de 45 kg.
5. Este producto se utiliza en columnas de paredes de madera maciza o paredes macizas.
6. Por razones de seguridad, confirme que la pared donde va a instalar el producto debe soportar el peso combinado del televisor, el soporte y los accesorios tres veces más.
7. Este producto solo se puede usar para esta función, no lo use para otros propósitos. El fabricante no se hace responsable de usos inadecuados.
8. El fabricante no será responsable de los daños a la vertical. pared causada por carga accidental o descargada.
9. El fabricante declara por la presente que no es responsable de ningún daño o daño causado por la instalación que no cumpla con los requisitos de responsabilidad.


move with
MOBIL 

SOPORTE PARA TV MB-TV5545




1

 Nivel Burbuja  Taladro  Lápiz  Broca 10mm




Sostener la placa a la pared y poner el nivel de burbuja encima. Nivelar hasta que la burbuja se ponga en el centro. Una vez nivelado, señalar en la pared los orificios para taladrar.

2



Hacer los taladros en las marcas señaladas en la pared. Introducir los tacos (A), poner la placa y atornillar con los tornillos (B) y las arandelas (C).

3




C  Ø16XØ6X1.5mm 4PCS
D  M5*25 4PCS
E  Ø10XØ8.0X10mm 4PCS

- Montar los perfiles a la TV, utilizando los tornillos (D) y arandelas (C).

- Prestar atención a la longitud de los tornillos a la TV. Si son demasiado largos, utilizar los espaciadores (E).

4



Montar la TV en la placa de la pared. Hacer entrar la ranura superior y después la inferior.

5






F  Tornillo de Seguridad M5*35mm 2PCS

Fijar bien los perfiles a la placa de la pared con el tornillo (F) entre el perfil y la placa de la pared.

TIPS!


Disclaimer:improper assembly or installation may result in injury or death, destruction of property.Please read this installation manual carefully before installation information.

1. The product must be installed by professionals.
2. If you do not understand, please contact a qualified local installer.
3. If the product is abnormal or missing, please do not assemble or install it. Please contact the local dealer get help.
4. This product is suitable for 26"-55" LCD/plasma screen, and can bear 45kg
5. This product is used on solid wood wall column or solid wall.
6. For safety reasons, please confirm that the wall of the installation product should bear the combined weight of the TV set, bracket and accessories three times as much.If the expansion tube on the wall is found to be loose during installation, please stop the installation.
7. This product can only be used for display in this range,please do not use for other purposes.
8. The manufacturer shall not be responsible for the damage to the vertical wall caused by unloaded or accidental load.
9. The manufacturer hereby declares that it is not liable for any damage or damage caused by the installation not in accordance with the requirements responsibility.




1

- Bubble Level
- Electric Drill
- Pencil
- Drill 10mm




1. Stick a pencil in the wall According to the product installation board installation. Draw points on the holes and drill them into place hole.

2



2. Put the expansion pipe (A) into the installation hole of the wall. Self-tapping screws (B). Fix the product mounting plate to the wall through the gasket (C).


3



- C Ø16XØ6X1.5mm 4PCS
- D M5*25 4PCS
- E Ø10XØ8.0X10mm 4PCS

3. Use round head screw (D) and gasket (C) to set the TV. Fixed on the installation board, according to their own needs or not to add high cushion.

4



4. Lock the TV set on hook Hang it on the wall mounting place.

5



- F Safety screw M5*35mm 2PCS

5. Fix the safety screw (F) finished the install.