



AFEITADORA Y RECORTADORA 2en1



MANUAL DE INSTRUCCIONES

TH-SH102




EAN: 8436572767447 (AZUL)

EAN: 8436572767461 (ROJO)

ESTIMADO CLIENTE.

Agradecemos la confianza depositada en nuestra marca THULOS®. Nuestro principal empeño es ofrecer artículos excelentes, manteniendo los más estrictos controles de calidad y cumpliendo todas las normativas vigentes de seguridad, con el objetivo de presentar un producto perfecto y seguro para el uso doméstico.

COMPONENTES DEL APARATO.



1. Hoja de corte.
2. On / Off.
3. Tapa protectora.
4. Cable Usb para cargar.
5. Cepillo de limpieza.
6. Aceite lubricante.
7. Conector de carga MicroUsb 5VDC.
8. Indicador de "cargando".
9. Accesorio recortador.

PRECAUCIONES Y ADVERTENCIAS.

- Leer y cumplir este manual bajo responsabilidad de exención de garantía.
- Mal uso y/o uso excesivo del aparato anula automáticamente la garantía.
- Nunca utilizar el aparato mientras esté enchufado cargando.
- Nunca cargar el aparato cerca de donde pueda salpicarle agua ó mojarse.
- Si el aparato se moja, secar inmediatamente.
- Mantener el aparato y accesorios alejados de fuentes calientes y de calor.
- No apto para niños. Este aparato no es un juego para niños.
- Supervisión extrema cuando sea utilizado por, sobre o cerca de niños o personas con necesidades especiales o ciertas discapacidades.
- Nunca utilizar el aparato con accesorios ó cable de carga dañados.
- El aparato solamente debe enchufarse a un adaptador de 5V-1A (Max.).
- Nunca utilizar el aparato cerca de aerosoles ó gases inflamables.
- Aparato diseñado únicamente para uso doméstico.
- Si el aparato no es utilizado durante un largo tiempo, poner en carga una vez al mes para conservar el buen estado de la batería.
- Las averías de batería no las cubren la garantía por considerarse pieza consumible por uso y desgaste.

FUNCIONAMIENTO.

- Antes del primer uso, cargar el aparato durante 16 horas.
- Las próximas cargas, cargar el aparato durante 8 horas.
- Nunca dejar que la batería se agote por completo.
- Retire la tapa protectora.
- Ponga el accesorio de corte que quiera utilizar.
- Para cambiar el accesorio de corte, presionar a la vez las dos pestañas laterales y tirar hacia arriba del accesorio.
Poner el otro accesorio alineando y después presionando hacia bajo.
- Pulsar el botón On/Off.
- Cuando termine, limpie el aparato, engrase y ponga la tapa protectora.
- Almacene el aparato en un lugar fresco, seco y libre de polvo.

ESPECIFICACIONES.

- Entrada de Voltaje: 5V 1A.
- Voltaje Motor: DC 2.4V
- Tiempo de carga: 8 hours
- Tiempo de Funcionamiento: 45min (aprox.).
- Capacidad de batería: Ni-MH 1/2AA 600mAh.
- Resistente al agua: IPX5.



SHAVER AND TRIMMER 2in1



INSTRUCTIONS MANUAL

TH-SH102




EAN: 8436572767447 (BLUE)

EAN: 8436572767461 (RED)

DEAR CUSTOMER.

We appreciate the trust placed in us when purchasing this THULOS® product. Our main effort is to offer excellent items, maintaining the strictest quality controls and complying with all current safety regulations, in order to present a perfect and safe product for domestic use.

PARTS OF THE APPLIANCE.



1. Cutting sheet.
2. On / Off.
3. Protective cover.
4. Usb cable to charge.
5. Cleaning brush.
6. Lubricating oil.
7. Charge connector
MicroUsb 5VDC.
8. Indicator of "loading".
9. Trimmer accessory.

PRECAUTIONS AND WARNINGS.

- Read and comply with this manual under warranty exemption responsibility.
- Misuse and / or excessive use of the device automatically voids the warranty.
- Never use the appliance while it is plugged in charging.
- Never charge the appliance near where you can splash water or get wet.
- If the appliance gets wet, dry immediately.
- Keep the appliance and accessories away from hot and hot sources.
- Not suitable for children. This device is not a game for children.
- Extreme supervision when used by, on or near children or people with special needs or certain disabilities.
- Never use the appliance with damaged accessories or charging cable.
- The device should only be plugged into a 5V-1A (Max.) Adapter.
- Never use the device near flammable aerosols or gases.
- Apparatus designed only for domestic use.
- If the device is not used for a long time, put in charge once a month to preserve the good condition of the battery.
- Battery faults are not covered by the warranty because they are considered part consumable by use and wear.

OPERATION.

- Before the first use, charge the device for 16 hours.
- The next charges, charge the device for 8 hours.
- Never let the battery run out completely.
- Remove the protective cap.
- Put the cutting attachment you want to use.
- To change the cutting attachment, press both tabs at the same time side and pull up the accessory.
Put the other accessory in alignment and then pressing down.
- Press the On / Off button.
- When finished, clean the device, lubricate and put on the protective cap.
- Store the device in a cool, dry and dust-free place.

SPECIFICATIONS.

- Voltage Input: 5V 1A.
- Motor Voltage: DC 2.4V
- Charging time: 8 hours
- Operating Time: 45min (approx.).
- Battery capacity: Ni-MH 1 / 2AA 600mAh.
- Water resistant: IPX5.