



CEPILLO SECADOR DE PELO

TH-HAB360

ESPECIFICACIONES

- Voltaje: 220V-230V / 50-60Hz.
- Potencia: 1200W.
- 3 Configuraciones entre velocidad y calor.
- Tecnología de Iones negativos.
- Cuerpo Ultra Ligero.
- Calentador de cerámica.
- Secado hasta un 60% más rápido.



ADVERTENCIAS POR Y PARA SU SEGURIDAD

- Mantener seco el aparato en todo momento.
- No usar en zonas con ambiente húmedo.
- No pueden usarlo niños ni personas con capacidades reducidas que no entiendan su funcionamiento y riesgos.
- Este aparato no es un juego para niños.

- No tocar los filamentos del aparato mientras esté encendido.
- Nunca usar si el cable o cualquier parte del aparato está dañada.
- Solamente puede ser reparado por un servicio técnico autorizado.
- Nunca usar cerca de donde pueda haber agua u otro líquido.
- Asegurarse de tener bien secas las manos y cuerpo antes de usar.
- No usar cerca de aerosoles, sprays o productos con gas comprimido.
- Desenchufar de la corriente cuando no lo esté usando.
- Nunca dejar desatendido mientras esté enchufado a la corriente.
- No usar extensores de cable, multiplicadores ni temporizadores.
- Nunca tapar la entrada de aire trasera.
- Nunca usar sin el filtro trasero.
- Mantener siempre limpio tanto el aparato como su filtro trasero.
- La marca se exime de cualquier responsabilidad por accidentes y/o averías causados por incumplimiento de estas instrucciones.

FUNCIONAMIENTO.

- Antes de enchufar, el selector debe estar en posición OFF.
- Revisar la rejilla trasera que no esté sucia ni obstruida.
- El cepillo tiene un selector con 4 posiciones.
 - (1) OFF. Cepillo apagado.
 - (2) LOW. Velocidad alta con temperatura media.
 - (3) MIDDLE. Velocidad media con temperatura media.
 - (4) HIGH. Velocidad alta con temperatura alta.

NOTA.

En el primer uso, durante los primeros minutos de uso, es normal si nota humo y un ligero olor, desaparecerá rápidamente. Esto es debido a la capa de aceite protector de fábrica para conservar el producto en perfecto estado hasta su venta y uso.

CONSERVACIÓN.

- Limpiar siempre el aparato después de cada uso.
- Antes de limpiar, desenchufar y dejar enfriar.
- Nunca usar productos de limpieza abrasivos, siempre neutros.
- Limpiar con paño suave y seco o, como mucho, ligeramente húmedo.
- Guardar hasta su próximo uso en zona fresca, seca y libre de polvo.



HOT AIR DRYER BRUSH

TH-HAB360



SPECIFICATIONS

- Voltage: 220V-230V / 50-60Hz.
- Power: 1200W.
- 3 settings between speed and heat.
- Negative ion technology.
- Ultra Light Body.
- Ceramic heater.
- Drying up to 60% faster.



WARNINGS BY AND FOR YOUR SAFETY

- Keep the device dry at all times.
- Do not use in areas with a humid environment.
- Cannot be used by children or people with reduced capacities who do not understand its operation and risks.
- This appliance is not a game for children.

- Do not touch the filaments of the device while it is on.
- Never use if the cable or any part of the device is damaged.
- It can only be repaired by an authorized technical service.
- Never use near where there may be water or other liquid.
- Make sure your hands and body are dry before use.
- Do not use near aerosols, sprays or products with compressed gas.
- Unplug from power when not in use.
- Never leave unattended while plugged in.
- Do not use cable extenders, multipliers or timers.
- Never cover the rear air intake.
- Never use without the rear filter.
- Always keep both the appliance and its rear filter clean.
- The brand disclaims any liability for accidents and/or breakdowns caused by non-compliance with these instructions.

OPERATING INSTRUCTIONS.

- Before plugging in, the selector must be in the OFF position.
- Check the rear grille that it is not dirty or obstructed.
- The brush has a selector with 4 positions.
 - (1) OFF. Brush off.
 - (2) LOW. High speed with medium temperature.
 - (3) MIDDLE. Medium speed with medium temperature.
 - (4) HIGH. High speed with high temperature.

NOTE.

In the first use, during the first minutes of use, it is normal if you notice smoke and a slight odor, it will disappear quickly.
This is due to the factory coating of protective oil to preserve the product in perfect condition until its sale and use.

CONSERVATION.

- Always clean the appliance after each use.
- Before cleaning, unplug and let cool.
- Never use abrasive cleaning products, always neutral.
- Clean with a soft, dry cloth or, at most, a slightly damp cloth.
- Store until its next use in a cool, dry and dust-free area.